


Controller



WARNING The MC-91-1 controller is not compatible with Alternate Temperature Settings. Alternate Temperature Settings are for commercial applications only. DO NOT use the MC-91-1 controller when dip switches 2 and 3 (white switches) are in the ON position.

Diagnostic Use of the Controller

1. To display the most recent diagnostic codes press and hold the "On/Off" button for 2 seconds on the MC-91 controller.
2. To enter or exit the maintenance monitor information mode press and hold the down button for 2 seconds and without releasing it press the ON/OFF button.

No.	Data	Unit
01	Water flow rate	0.1 gpm/in
02	Outgoing water temperature	Degrees Fahrenheit

To Change the Temperature Scale (°F / °C)
With the water heater turned off, press and hold the ON/OFF button until the display changes to the other temperature scale (about 5 seconds).

To Turn Off the Controller Sound (Mute)
To turn the sound off (mute), press and hold both the ▲ and ▼ thermostat buttons until a "beep" is heard (about 5 seconds).


Locking the Controller
The MC-91-2 controller can be locked or unlocked by pressing the Priority button and the up button together for 5 seconds. A beep will sound confirming that the controller is locked. The display will alternately show "LOC", the temperature setting, and a diagnostic code if one has been activated. All of the controllers in the system are also locked.

To unlock the controller press the Priority button and the up button together for 5 seconds.

Gas Pressure Setting

Ensure gas pressure check under Commissioning has been completed first! The regulator is electronically controlled and factory pre-set. Under normal circumstances it does not require adjustment during installation. Make adjustments only if the unit is not operating correctly and all other possible causes for incorrect operation have been eliminated.

1. Turn OFF the gas supply.
2. Turn OFF the gas supply.
3. Remove the front panel (four screws).
4. Check the gas type using the data plate on the side of the unit. Confirm that the gas type switch is in the correct position (switch 1 of Dip SW2 is ON for natural gas, NG, and OFF for propane gas, LPG.) Figure 1.
5. Remove the screw and attach the manometer to the burner test point located on the gas control. Figure 2.
6. Turn on the gas supply and the power supply.
7. Flow water through the water heater at the maximum flow rate obtainable. (At least 3 gallons per minute is recommended. If there is not enough water flowing, the water heater could shut off or sustain damage due to overheating.)
8. Move switch 8 of Dip SW1 to ON. Figure 3.
9. Push the PC board switch A for one second. Figure 4.
10. Calibrate "Forced Low" combustion using switch A (up) and switch B (down).
11. Move switch 8 of Dip SW1 to OFF and then back to ON. Figure 6.
12. Push the PC board switch B for one second. Figure 4.
13. Calibrate "Forced High" combustion using switch A (up) and switch B (down).
14. Move switch 8 of Dip SW1 to OFF. Figure 5.
15. Close hot water taps.
16. Turn off gas supply and 120 V power supply.
17. Remove manometer and re-install allen head plug.
18. Turn on the gas supply and 120 V power supply.
19. Operate the unit and check for gas leaks.
20. Install the front panel using four screws.



Gas Pressure Setting

NOTE: For additional installation and commissioning information refer to the Operation and Installation Manual.

WARNING This appliance must be installed, serviced and removed by a trained and qualified person. During pressure testing of the consumer piping, ensure gas valve is turned off before unit is shut off. Failure to do so may result in serious injury to yourself or damage to the unit.

APPLIANCE OPERATING PRESSURES Table 1

	Water Inlet Max.	Gas Inlet Min./Max		Forced Low		Forced High	
		NAT.G	LPG	NAT.G	LPG	NAT.G	LPG
UGT-199	Short Run length 150 PSI	4"W.C. (10.57W.C.)	8"W.C. (19.33W.C.)	0.81"W.C. 0.87"W.C.	3.0"W.C. 3.4"W.C.	4.8"W.C. 5.3"W.C.	10.5"W.C. 11.6"W.C.
UGT-180	Short Run length Long Run length	4"W.C. (10.57W.C.)	8"W.C. (19.33W.C.)	0.81"W.C. 0.87"W.C.	2.5"W.C. 2.9"W.C.	3.9"W.C. 4.3"W.C.	10.5"W.C. 11.6"W.C.

Commissioning
With all gas appliances in operation at maximum gas rate, the flowing inlet pressure at the incoming test point on the water heater should read 4" W.C. - 10.5" W.C. on natural gas and 8" W.C. - 13.5 W.C. on propane gas. If the pressure is lower, the gas supply is inadequate and the unit will not operate to specification. Check the gas meter regulator and pipework for correct operation/sizing and correct as required.

Troubleshooting

Important Safety Notes
There are a number of (live) tests that are required when fault finding this product. Extreme care should be used at all times to avoid contact with energized components inside the water heater. Only trained and qualified service technicians should attempt to repair this product. Before checking for resistance readings, disconnect the power source to the unit and isolate the item from the circuit (snugging it).

(SV1, SV2, SV3, SV4 and P0V) Gas valve and Modulating solenoids: (Set meter above 2K)

Wire color	Voltage	Resistance	Connector #	Pin #s
(Main) Black - Grey	11 - 13 VDC	24 - 28 ohms	D1	83 - 84
(SV1) Black - Blue	11 - 13 VDC	36 - 42 ohms	B3	4 - 6
(SV2) Black - Yellow	11 - 13 VDC	36 - 42 ohms	B2	4 - 7
(SV3) Black - Red	11 - 13 VDC	36 - 42 ohms	B4	4 - 5
(SV4) Black - Orange	11 - 13 VDC	35 - 41 ohms	B1	4 - 8
(P0V) Pink - Pink	2 - 15 VDC	67 - 81 ohms	D1	1 - 2

(M) Water Flow Control Device Servo or Geared Motor:

Color	Voltage	Resistance	Terminal	Pin #
Red - Pink	5 - 8 VDC	44 - 52 ohms	G2	3 - 4
White - Blue	5 - 8 VDC	44 - 52 ohms	G2	1 - 2
Green - Brown	N/A	N/A	G2	5 - 7
Gray - Orange	N/A	N/A	G2	6 - 7

NOTE: The grey wire listed above turns to black at G connector on the PCB.

(Q3) Water Flow Sensor:

Color	Voltage	Resistance	Terminal	Pin #
Black - Red	11 - 13 VDC	5.5 - 6.2 K ohms	L3	E10 - G7
Yellow - Black	4 - 7 VDC	1 - 1.4 Mega ohms	L3	E1 - G7

By-pass Flow Control:

Color	Voltage	Resistance	Terminal	Pin #
Red - Pink	2 - 6 VDC	44 - 52 ohms	G1	12 - 13
White - Blue				

(IG) Ignition System:

Color	Voltage	Resistance	Terminal	Pin #
Green - Grey	90 - 110 VAC	N/A	C1	1 - 3

(FM) Combustion Fan Motor:

Color	Voltage	Resistance	Terminal	Pin #
Red - Black	16 - 45 VDC	N/A	L2	5 - 6
White - Black	5 - 10 VDC	N/A	L2	3 - 5
Yellow - Black	11 - 13 VDC	N/A	L2	4 - 5

Set your meter to the hertz scale. Reading across the white and black wires at terminals 3 and 5 should read between 60 and 420 hertz.

Thermal Fuse / Overheat Switch:

Color	Voltage	Resistance	Terminal	Pin #
White - White	11 - 13 VDC	Below 1 ohms	BB B7	B1 - E10

Flame Rod:

Place one lead of your meter to the flame rod and the other to ground. With the unit running you should read between 5-150 VAC. Set your meter to the μ amp scale and series your meter in line with the flame rod. You should read 1 μ amp or greater for proper flame circuit. In the event of low flame circuit remove the flame rod and check for carbon or damage.

Heat Exchanger, Outgoing Water Temperature and Inlet Thermistors:

Check all thermistors by inserting meter leads into each end of the thermistor plug. Set your meter to the 20 K scale and read resistance. Applying heat to the thermistor bulb should decrease the resistance. Applying ice to the thermistor bulb should increase the resistance. See below for examples of typical temperatures and resistance readings.

Example: 59°F = 11.4 - 14KΩ 140°F = 2.2 - 2.7KΩ
88°F = 6.4 - 7.8KΩ 221°F = 0.6 - 0.8KΩ
113°F = 3.6 - 4.5KΩ

Outgoing Water Thermistor:

Color	Voltage	Resistance	Terminal	Pin #
White - White	N/A	See example above	E5	2 - 3
Blue - Blue	N/A	See example above	E5	4 - 5

Heat Exchanger Temperature Thermistor:

Color	Voltage	Resistance	Terminal	Pin #
Pink - Pink	N/A	See example above	E4	4 - 7

Inlet Thermistor:

Color	Voltage	Resistance	Terminal	Pin #
White - White	N/A	See example above	E7	4 - 9

Remote Controls:

Terminals	Voltage	Resistance	Terminal	Pin #
J	10 - 13 VDC	1.5 - 3.0 K ohms	J	1 - 2


Frost Protection:
This unit has frost protection heaters mounted at different points to protect the water heater from freezing. All of them should show a positive resistance reading.

Amp Fuses:
This unit has one inline (10) amp glass fuse. Remove the fuse and check continuity through it. If you have continuity through the fuse then it is good. Otherwise the fuse is blown and must be replaced.

Dip Switches Settings

Adjust switches 2 and 3 of Dip SW1 (upper side) depending on your altitude according to the table below.

Dip SW No.	High Altitude	Off	Level 0 (0-2000 ft) (0-610 m)	On	Level 1 (2001-5200 ft) (610-1585 m)	Off	Level 2 (5201-7700 ft) (1585-2347 m)	On	Level 3 (7701-10200 ft) (2347-3109 m)
2	High Altitude	Off	Level 0	Off	Level 1	On	Level 2	On	Level 3
3	High Altitude	Off	Level 0	On	Level 1	Off	Level 2	Off	Level 3



WARNING
DO NOT adjust the other dip switches unless specifically instructed to do so. Incorrect Dip Switch Settings can cause the water heater to operate in an unsafe condition and may damage the water heater and void the warranty.

Diagnostic Codes

03 Power interruption during Bath fill (Water will not flow when power returns)

- Turn off all hot water taps. Press ON/OFF twice.

10 Air Supply or Exhaust Blockage

- Ensure approved venting materials are being used.
- Check that nothing is blocking the flue inlet or exhaust.
- Check all vent components for proper connections.
- Ensure vent length is within limits.
- Verify dip switches are set properly.
- Check fan for blockage.

11 No Ignition

- Check that the gas is turned on at the water heater, meter, or cylinder.
- If the system is propane, make sure that gas is in the tank.
- Ensure appliance is properly grounded.
- Ensure gas type and pressure is correct.
- Ensure gas line, meter, and/or regulator is sized properly.
- Bleed all air from gas lines.
- Ensure igniter is operational.
- Check igniter wiring harness for damage.
- Check gas solenoid valves for open or short circuits.
- Remove burner cover and ensure burners are properly seated.
- Remove burner plate; inspect burner surface for condensation/debris.

12 No Flame

- Check that the gas is turned on at the water heater, meter, or cylinder.
- Check for obstructions in the flue outlet.
- If the system is propane, make sure that gas is in the tank.
- Ensure gas line, meter, and/or regulator is sized properly.
- Ensure gas type and pressure is correct.
- Bleed all air from gas lines.
- Ensure proper venting material was installed.
- Ensure condensation collar was installed properly.
- Ensure vent length is within limits.
- Verify dip switches are set properly.
- Check power supply for loose connections.
- Check power supply for proper voltage and voltage drops.
- Ensure flame rod wire is connected.
- Check flame rod for carbon build-up.
- Disconnect and reconnect all wiring harnesses on unit and PC board.
- Check for DC shorts at components.
- Check gas solenoid valves for open or short circuits.
- Remove burner plate; inspect burner surface for condensation/debris.
- Check the ground wire for the PC board.

14 Thermal Fuse

- Check for restrictions in air flow around unit and vent terminal.
- Check gas type of unit and ensure it matches gas type being used.
- Check for low water flow in a circulating system causing short-cycling.
- Ensure dip switches are set to the proper position.
- If switch #5 in the SW2 bank is in the OFF position, turn it to the ON position.
- Check for foreign materials in combustion chamber and exhaust piping.
- Check heat exchanger for cracks or separations.
- Check heat exchanger surface for hot spots which indicate blockage due to scale build-up. Refer to instructions in manual for flushing heat exchanger. Hard water must be treated to prevent scale build up/damage.
- Measure resistance of safety circuit.
- Ensure high fire and low fire manifold pressure is correct.
- Check for improper conversion of product.

16 Over Temperature Warning

- Check for restrictions in air flow around unit and vent terminal.
- Check for low water flow in a circulating system causing short-cycling.
- Check for foreign materials in combustion chamber and exhaust piping.
- Check for blockage in the heat exchanger.

19 Electrical Grounding

- Check all components for electrical short.

32 Outgoing Water Temperature Sensor

33 Heat Exchanger Outgoing Temperature Sensor

34 Combustion Air Temperature Sensor Fault

- Check for restrictions in air flow around unit and vent terminal.
- Check sensor wiring for damage.
- Measure resistance of sensor.
- Clean sensor of scale build up.
- Ensure fan blade is tight on motor shaft and is in good condition.
- Replace sensor.

51 Inlet Water Temperature Sensor (UGT-199 only)

- Check sensor wiring for damage.
- Measure resistance of sensor.
- Clean sensor of scale build-up.
- Replace sensor.

52 Modulating Solenoid Valve Signal

- Check modulating gas solenoid valve wiring harness for loose or damaged terminals.
- Measure resistance of valve coil.

61 Combustion Fan

- Ensure fan will turn freely.
- Check wiring harness to motor for damaged and/or loose connections.
- Measure resistance of motor winding.

65 Water Flow Servo

- The water flow control valve has failed to close during the bath fill function. Immediately turn off water and discontinue the bath fill function. Contact a licensed professional.

70 PC Board

- Check PC board DIP switches for correct positions.
- Check the connection harness at the connection on the PC board.
- Replace PC board.

71 Solenoid Valve Circuit

- Replace the PC Board.

72 Flame Sensing Device

- Verify flame rod is touching flame when unit fires.
- Check all wiring to flame rod.
- Remove flame rod; check for carbon build-up; clean with sand paper.
- Check inside burner chamber for any foreign material blocking flame at flame rod.
- Measure micro amp output of sensor circuit with flame present.
- Replace flame rod.

79 Water leakage detected

- Turn off water supply and contact licensed professional.

LC# Scale Build-up in Heat Exchanger (when checking maintenance code history "00" is substituted for "LC")


- LC0-LC9 indicates that there is scale build up in the heat exchanger and that the heat exchanger needs to be flushed to prevent damage. Refer to the flushing instructions in the manual. Hard water must be treated to prevent scale build up or damage to the heat exchanger.
- To operate the water heater temporarily until the heat exchanger can be flushed, push the On/Off button on the temperature controller 5 times. Repeated LCF codes will eventually lock out the water heater.

FF Maintenance Performed


- Indicates a service provider performed maintenance or repair. Enter this code by pressing up, down, and ON/OFF simultaneously.

No Code (Nothing happens when water flow is activated.)


- Clean inlet water supply filter.
- On new installations ensure hot and cold water lines are not reversed.
- Verify you have at least the minimum flow rate required to fire unit.
- Check for cold to hot cross over. Isolate circulating system if present.
- Turn off cold water to the unit, open pressure relief valve; if water continues to flow, there is bleed over in your plumbing.
- Verify turbine spins freely.
- Measure the resistance of the water flow control sensor.
- If the display is blank and clicking is coming from the unit, disconnect the water flow servo motor (GY, BR, O, W, P, BL, R). If the display comes on then replace the water flow servo motor.



EXPLODED VIEW - CABINET



EXPLODED VIEW - INTERNALS



Item Description	Part Number	Qty	UGT-199	UGT-180	Item Description	Part Number	Qty	UGT-199	UGT-180
001 MAIN BODY	109000364	1	1		720 POWER CORD ASSEMBLY	CP-90580	1	1	
002 WALL BRACKET	109000259	2	2		724 SENSOR HARNESS-1	105000163	1	1	
004 CONNECTION REINFORCEMENT	109000261	1	1		724 SENSOR HARNESS-5	105000191	1	1	
006 FRONT PANEL	109000365	1	1		725 FUSE HARNESS	105000167	1	1	
008 FRONT PANEL PACKING	109000367	1	1		726 POWER SUPPLY HARNESS	105000183	1	1	
009 TEMPERATURE CONTROL	U245-3185-2	2	2		727 WATER FLOW SENSOR	105000176	1	1	
010 TEMPERATURE CONTROL PLATE	109000186	1	1		728 IGNITOR BRACKET	109000272	1	1	
016 SCREW COVER	109000197	2	2		730 TWIN THERMISTOR	105000108	1	1	
001 GAS CONTROL ASSEMBLY	106000085	1	1		731 SOLENOID HARNESS	105000168	1	1	
100 TEST PORT SET SCREW	C100-5	2	2		732 INLET AIR THERMISTOR	105000029	1	1	
102 3/4 GAS INLET	106000065	1	1		733 THERMISTOR	H111-650	1	1	
103 BURNER UNIT ASSY (LPG)	106000072	1	1		734 SENSOR BRACKET	109000273	1	1	
103 BURNER UNIT ASSY (NG)	106000073	1	1		735 SCREW	105000029	1	1	
104 BURNER CASE FRONT PANEL	106000074	1	1		740 HEATER	105000154	1	1	
106 PACKING	109000264	1	1		741 HEATER	105000169	1	1	
107 BURNERS	106000054	17	17		742 HEATER	105000171	1	1	
108 BURNER CASE BACK PANEL	106000075	1	1		800 TRUSS SCREW	CP-30580-2	8	8	
109 DAMPER (LPG)	106000076	1	1		801 TRUSS SCREW	CP-30580	4	4	
109 DAMPER (NG)	106000077	1	1		802 NYLON WASHER	AU33-184X01	4	4	
110 MANIFOLD ASSEMBLY (LPG)	106000078	1	1		803 SCREW	109000280	2	2	
110 MANIFOLD ASSEMBLY (NG)	106000079	1	1		804 SCREW	U217-449	2	2	
111 COMB CHAMBER PACKING UPPER	106000080	1	1		805 SCREW	CP-20883-410UK	3	2	
112 COMB CHAMBER PACKING LOWER	106000081	1	1		807 PLASTIC WASHER	AU48-174	2	2	
114 COMB CHAMBER FRONT PANEL	106000082	1	1		810 O-RING	M10B-2-4	3	3	
115 COMB CHAMBER PACKING - 2	106000083	1	1		811 O-RING	M10B-2-3	1	1	
116 ELECTRODE	105000179	1	1		812 O-RING	M10B-2-10	1	1	
117 FLAME ROD	105000093	2	2		813 O-RING	M10B-2-18	3	2	
118 ELECTRODE BRACKET	105000156	1	1		814 O-RING	M10B-2-18	1	1	
119 ELECTRODE PACKING	105000157	1	1						