


Enhancing everyday living



A DANGER

This manual must only be used by a qualified heating installer/service technician. Read and understand all instructions in this manual before installing. Perform steps in the order given. Failure to comply will result in substantial property damage, severe personal injury, or death.

AQMD

NOTICE: GIANT reserves the right to make product changes or updates without notice and will not be held liable for typographical errors in literature.


NOTE TO CONSUMER: PLEASE KEEP ALL INSTRUCTIONS FOR FUTURE REFERENCE.

www.giantinc.com GI-IM048En-1013

IF THE INFORMATION IN THIS MANUAL IS NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT, CAUSING PROPERTY DAMAGE, PERSONAL INJURY, OR LOSS OF LIFE. DO NOT STORE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch.
- Do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department. Installation and service must be provided by a qualified installer, service agency, or the gas supplier.



SPECIAL ATTENTION BOXES

The following defined terms are used throughout this manual to bring attention to the presence of hazards of various risk levels, or to important product information.

A DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

FOREWORD

This manual is intended to be used in conjunction with other literature provided with the Phoenix Gas-Fired Water Heater. This includes all related control information. It is important that this manual, all other documents included with this system, and additional publications including the National Fuel Gas Code, ANSI Z223.1-2002, be reviewed in their entirety before beginning any work.

Installation should be made in accordance with the regulations of the Authority Having Jurisdiction, local code authorities, and utility companies which pertain to this type of water heating equipment.

Authority Having Jurisdiction (AHJ) – The Authority Having Jurisdiction may be a federal, state, local government, or individual such as a fire chief, fire marshal, chief of a fire prevention bureau, labor department or health department, building official or electrical inspector, or *others having statutory authority*. In some circumstances, the property owner or his/her agent assumes the role, and at government installations, the commanding officer or departmental official may be the AHJ.

NOTE: GIANT, Inc. reserves the right to modify product technical specifications and components without prior notice.

FOR THE INSTALLER

A DANGER

This manual must only be used by a qualified heating installer/service technician. Read and understand all instructions in this manual before installing. Perform steps in the order given. Failure to comply will result in substantial property damage, severe personal injury, or death.

This water heater must be installed by qualified and licensed personnel. The installer should be guided by the instructions furnished with the heater, and with local codes and utility company requirements. In the absence of local codes, preference should be given to the National Fuel Gas Code, ANSI Z223.1-2002.

INSTALLATIONS MUST COMPLY WITH:

Local, state, provincial, and national codes, laws, regulations and ordinances.

The latest version of the National Fuel Gas Code, ANSI Z223.1, from American Gas Association Laboratories, 8501 East Pleasant Valley Road, Cleveland, OH 44131.

In Canada – CGA No. B149 (latest version), from Canadian Gas Association Laboratories, 55 Scarsdale Road, Don Mills, Ontario, Canada M3B 2R3. Also, Canadian Electrical Code C 22.1, from Canadian Standards Association, 5060 Spectrum Way, Suite 100, Mississauga, Ontario, Canada L4W 5N6.

Code for the installation of Heat Producing Appliances (latest version), from American Insurance Association, 85 John Street, New York, NY 11038.

The latest version of the National Electrical Code, NFPA No. 70.

NOTE: The gas manifold and controls met safe lighting and other performance criteria when undergoing tests specified in ANSI Z21.10.3 – latest edition.

TABLE OF CONTENTS

FOREWORD	3
FOR THE INSTALLER	3
PART 1 – GENERAL SAFETY INFORMATION	6
A. PRECAUTIONS	6
B. IMPROPER COMBUSTION	6
C. GAS	6
D. WHEN SERVICING THE HEATER	6
E. HEATER WATER	6
PART 2 – BEFORE YOU START	7
A. WHAT'S IN THE BOX	7
B. HOW THE HEATER OPERATES	7
C. OPTIONAL EQUIPMENT	8
PART 3 – PREPARE WATER HEATER LOCATION	8
A. BEFORE LOCATING THE HEATER	9
B. LEVELING	9
C. CLEARANCES FOR SERVICE ACCESS	10
D. RESIDENTIAL GARAGE INSTALLATION	10
E. EXHAUST VENT AND INTAKE PIPE	
1. DIRECT VENT INSTALLATION OF EXHAUST VENT AND INTAKE PIPE	
2. INDOOR COMBUSTION AIR INSTALLATION IN CONFINED OR UNCONFINED SPACE	
F. PREVENT COMBUSTION AIR CONTAMINATION	
G. REMOVING A HEATER FROM A COMMON VENT SYSTEM	
H. WATER CHEMISTRY	
PART 4 – HEATER PIPING	
A. GENERAL PIPING INFORMATION	
B. SCALDING	
C. TEMPERATURE AND PRESSURE RELIEF VALVE	
D. BACKFLOW PREVENTER	
E. POTABLE EXPANSION TANK	
F. WATER PIPING	
G. AUXILIARY CONNECTIONS	
H. PIPING DIAGRAM	
PART 5 – VENTING, COMBUSTION AIR AND CONDENSATE REMOVAL	
A. GENERAL	
B. APPROVED MATERIALS FOR EXHAUST VENT AND INTAKE PIPE	
C. REQUIREMENTS FOR INSTALLATION IN CANADA	
D. EXHAUST VENT AND INTAKE PIPE LOCATION	
1. DETERMINE EXHAUST VENT LOCATION	
E. EXHAUST VENT AND INTAKE PIPE SIZING	27

F. LONGER VENT RUNS	
G. EXHAUST VENT AND INTAKE PIPE INSTALLATION	
H. VENTING DRAWINGS	
1. DIRECT VENT INSTALLATION OF EXHAUST VENT AND INTAKE PIPE	
2. VENTING THROUGH AN EXISTING SYSTEM	
3. INDOOR COMBUSTION AIR INSTALLATION IN CONFINED OR UNCONFINED SPACE	
I. CONDENSATE REMOVAL SYSTEM	
PART 6 – WIRING	
A. LINE VOLTAGE INPUT	
B. LINE VOLTAGE CONDENSATE OUTPUT	
C. LOW VOLTAGE OUTDOOR SENSOR INPUT	
D. INTERNAL WIRING DIAGRAM	
PART 7 – GAS CONNECTIONS	41
A. GAS PIPING	
B. GAS TABLE	
C. GAS VALVE	
PART 8 – START-UP PROCEDURE	43
A. OPERATING INSTRUCTIONS	
B. OVERALL WATER HEATER AND CONTROL OPERATION	
C. STATUS MENU	
D. OUTDOOR RESET	44
E. TEST MODE	45
F. MAINTENANCE	
PART 9 – SHUTDOWN	46
A. SHUTDOWN PROCEDURE	
B. VACATION PROCEDURE	
C. FAILURE TO OPERATE	
PART 10 – TROUBLESHOOTING	46
A. ERROR CODE	
B. HEATER ERROR	
C. LOCKOUT	46
PART 11 - MAINTENANCE	51
MAINTENANCE NOTES	52
GIANT CUSTOMER INSTALLATION RECORD FORM	

PART 1 – GENERAL SAFETY INFORMATION

A. PRECAUTIONS

This water heater is for indoor installations only. Clearance to combustible materials: 0" top, bottom, sides and back. Unit must have room for service: 24" (61 cm) front and 12" (30 cm) sides are minimum recommended service clearances. (A combustible door or removable panel is acceptable front clearance.) This water heater has been approved for closet installation, and installation on combustible flooring. Do not install this water heater directly on carpeting. Use only Category IV vent systems.

INSTALLER – Read all instructions in this manual before installing. Perform steps in the order given.

USER – This manual is for use only by a qualified heating installer/service technician. Have this heater serviced/inspected by a qualified service technician annually.

FAILURE TO ADHERE TO THE GUIDELINES ON THIS PAGE AND HAVE THIS HEATER SERVICED/INSPECTED ANNUALLY CAN RESULT IN SUBSTANTIAL PROPERTY DAMAGE, SEVERE PERSONAL INJURY, OR DEATH.

A WARNING

If the heater is exposed to the following, do not operate until all corrective steps have been made by a qualified serviceman: 1. FIRE

1. FIRE

2. DAMAGE

3. WATER

Any claims for damage or shortage in shipment must be filed immediately against the transportation company by the consignee.

A WARNING

DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN SUBMERGED IN WATER. Immediately call a qualified service technician. The appliance MUST BE replaced if it has been submerged. Attempting to operate an appliance that has been submerged could create numerous harmful conditions, such as a potential gas leakage causing a fire and/or explosion, or the release of mold, bacteria, or other harmful particulates into the air. Operating a previously submerged appliance could result in property damage, severe personal injury, or death.

NOTE: Appliance damage due to flood or submersion is considered an Act of God, and IS NOT covered under product warranty.

B. IMPROPER COMBUSTION

A WARNING

Do not obstruct the flow of combustion and ventilating air. Adequate air is necessary for safe operation. Failure to keep the vent and combustion air intake clear of ice, snow, or other debris could result in property damage, serious personal injury, or death.

<u>C. GAS</u>


Should overheating or gas supply fail to shut off, turn off the manual gas control valve to the water heater.


D. WHEN SERVICING THE HEATER

- To avoid electric shock, disconnect electrical supply before performing maintenance.
- To avoid severe burns, allow heater to cool.

E. HEATER WATER

- Do not use petroleum-based cleaning or sealing compounds in a heater system. Gaskets and seals in the system may be damaged. This can result in substantial property damage.
- Do not use "homemade cures" or "heater patent medicines". Substantial property damage, damage to heater, and/or serious personal injury may result.





PART 2 – BEFORE YOU START

A. WHAT'S IN THE BOX

Also included with the heater:

- Intake PVC Tee with Screens
- Exhaust PVC Coupling with Screens
- Temperature and Pressure Relief Valve
- Installation Manual
- Warranty
- Solar Addendum (Solar Models Only)
- LP Conversion Kit (Natural Gas Models Only)

B. HOW THE HEATER OPERATES

Modulation Condensing Technology is an intelligent system that delivers highly efficient water heating, while maximizing efficiency by measuring the data parameters of your water heating system. Some of its features are:

Stainless Steel Water Storage Tank

The stainless steel water storage tank has a combustion chamber submerged into the tank water. When the water heater is fired, combustion gases heat the combustion chamber walls, transferring heat directly into the surrounding water. These hot gases are blown into secondary heat exchanger coils, where more heat is transferred into the water, removing even more heat from the gases.

Modulating Combustion System

Modulation during water heating operation is based on tank temperature. The control monitors the system to regulate burner output during operation to match system demand. This increase in efficiency allows for substantial fuel savings.

Gas Valve

The gas valve senses suction from the blower, allowing gas to flow only if the gas valve is energized and combustion air is flowing.

Upper Supply Tank Sensor

This sensor monitors the upper portion water temperature (system supply) of the water heater. The control module adjusts the burner firing rate so the outlet water temperature meets the set point.

Lower Return Tank Sensor

This sensor monitors the lower portion of the water heater inlet water temperature (system return). The control module reduces or increases input, depending on how close the water temperature is to the outlet water temperature set point.

Control

The integrated control system monitors upper and lower water temperature and regulates fan speed to regulate the unit's energy output. This allows the unit to deliver the required amount of heated energy and nothing more.

Burner

Constructed of high grade stainless steel, the burner uses pre-mixed air and gas and provides a wide range of firing rates.

Condensate Drain Connection


This is a condensing high efficiency water heater, and therefore has a condensate removal system. Condensate is nothing more than water vapor, derived from combustion products and similar to an automobile when it is initially started. It is very important that the condensate line slopes away from the water heater and down to a suitable inside drain.

If the condensate outlet on the heater is lower than the drain, you must use a condensate removal pump (kit p/n 554200 available from GIANT.) In addition, local authorities may require a condensate neutralizer to neutralize the condensate. Condensate neutralizers are made up of lime crystals, marble or phosphate chips. Neutralizers can be installed in the field by the installer and purchased from GIANT (p/n 7450P-212).

It is also very important not to expose the condensate line to freezing temperatures or any type of blockage. Plastic tubing must be the only material used for the condensate line. Steel, brass, copper or other materials will be subject to corrosion or deterioration. A second vent may be necessary to prevent condensate line vacuum lock on a long horizontal run. Also, an increase in pipe size may be necessary to allow condensate to drain properly. Support of the condensation line may be necessary to avoid blockage of the condensate flow.

Spark Ignition

The burner flame is ignited by applying high voltage to the system spark electrode. This causes a spark from electrode to ground.



C. OPTIONAL EQUIPMENT

Below is a list of optional equipment available from GIANT:

- 3" (7.6 cm) Stainless Steel Outside Termination Vent Kit (V1000)
- 4" (10 cm) Stainless Steel Outside Termination Vent Kit (V2000)
- 2" (5 cm) PVC Concentric Vent Kit (Part # KGAVT0501CVT)
- 3" (7.6 cm) PVC Concentric Vent Kit (Part # KGAVT0601CVT)
- 3" (7.6 cm) Polypro Vent Kit (Part # 8400P-001)
- 3" (7.6 cm) Polypro Pipe (33' (10 m) length Part # 8400P-002, 49.5' (15 m) length Part # 8400P-003)
- PC Connection Kit (Part # 7250P-320)
- Condensate Neutralizer (Part # 7450P-212)
- Outdoor Sensor (Part # 7250P-319)
- Sanitizer Booster Kit (Part # VSBK-1200)

PART 3 – PREPARE WATER HEATER LOCATION

CAUTION

Carefully consider installation when determining heater location. Please read the entire manual before attempting installation. Failure to properly take factors such as heater venting, piping, condensate removal, and wiring into account before installation could result in wasted time, money, and possible property damage and personal injury.

A. BEFORE LOCATING THE HEATER

Incorrect ambient conditions can lead to damage to the heating system and put safe operation at risk. Ensure that the heater installation location adheres to the information included in this manual. Failure to do so could result in property damage, serious personal injury, or death.

CAUTION

Failure of heater or components due to incorrect operating conditions IS NOT covered by product warranty.

1. Installation Area (Mechanical Room) Operating Conditions

- Ensure ambient temperatures are higher than 32°F (0°C) and lower than 104°F (40°C).
- Prevent the air from becoming contaminated by the products, places, and conditions listed in this manual, Part 3, Section F.
- Avoid continuously high levels of humidity
- Never close existing ventilation openings
- Ensure a minimum 1" (2.5 cm) clearance around hot water and exhaust vent pipes

CAUTION

The service life of the heater's exposed metallic surfaces, such as the casing, as well as internal surfaces, such as the heat exchanger, are directly influenced by proximity to damp and salty marine environments. In such areas, higher concentration levels of chlorides from sea spray coupled with relative humidity can lead to degradation of the heat exchanger and other heater components. In these environments, heaters must not be installed using direct vent systems which draw outdoor air for combustion. Such heaters must be installed using room air for combustion. Indoor air will have a much lower relative humidity and, hence, potential corrosion will be minimized.

A WARNING

This heater is certified for indoor installations only. Do not install the heater outdoors. Failure to install this heater indoors could result in substantial property damage, severe personal injury, or death.

2. Check for nearby connections to:

- System water piping
- Venting connections
- Gas supply piping
- Electrical power
- Condensate drain

3. Check area around heater. Remove any combustible materials, gasoline, and other flammable liquids.

Failure to keep heater area clear and free of combustible materials, liquids, and vapors can result in substantial property damage, severe personal injury, or death.

4. Gas control system components must be protected from dripping water during operation and service.

5. If the heater is to replace an existing heater, check for and correct any existing system problems, such as:

- System leaks
- Location that could cause the system and heater to freeze and leak.
- Incorrectly-sized expansion tank

6. Clean and flush system when reinstalling a heater.

NOTE: When installing in a zero clearance location, it may not be possible to read or view some product labeling. It is recommended to make note of the heater model and serial number.

B. LEVELING

In order for the condensate to properly flow out of the collection system, the area where you locate the heater must be level. Location must also fully support the weight of the filled water heater.

C. CLEARANCES FOR SERVICE ACCESS




Figure 1: Minimum Service Clearances

NOTE: If you do not provide the minimum clearances shown in Figure 1, it might not be possible to service the heater without removing it from the space.

\Lambda WARNING

The space must be provided with combustion/ventilation air openings correctly sized for all other appliances located in the same space as the heater. The heater cover must be securely fastened to prevent the heater from drawing air form the heater room. This is particularly important if the heater is in a room with other appliances. Failure to comply with the above warnings could result in substantial property damage, severe personal injury, or death.

D. RESIDENTIAL GARAGE INSTALLATION

PRECAUTIONS

If the heater is located in a residential garage, per ANSI Z223.1:

- Mount the bottom of the heater a minimum of 18" (46 cm) above the floor of the garage, to ensure the burner and ignition devices are well off the floor.
- When raising the heater, fully support the entire bottom of the water heater.
- Locate or protect the heater so it cannot be damaged by a moving vehicle.

E. EXHAUST VENT AND INTAKE PIPE

The heater is rated ANSI Z21.10.3 Category IV (pressurized vent, likely to form condensate in the vent) and requires a special vent system designed for pressurized venting.

NOTE: The venting options described here (and further detailed in Venting, Part 5 in this manual) are the lone venting options approved for this water heater. Failure to vent the water heater in accordance with the provided venting instructions will void the warranty.

🛦 DANGER

Failure to vent the water heater properly will result in serious personal injury or death.

A WARNING

Vents must be properly supported. Heater exhaust and intake connections are not designed to carry heavy weight. Vent support brackets must be within 1' (30 cm) of the heater and the balance at 4' (1.2 m) intervals. Heater must be readily accessible for visual inspection for the first 3' (91 cm) from the heater.

1. DIRECT VENT INSTALLATION OF EXHAUST VENT AND INTAKE PIPE

If installing a direct vent option, combustion air must be drawn from the outdoors directly into the water heater intake, and exhaust must terminate outside. There are three basic direct vent options detailed in this manual:

- 1. Side Wall Venting
- 2. Roof Venting
- 3. Unbalanced Venting

Be sure to locate the heater such that the exhaust vent and intake piping can be routed through the building and properly terminated. Different vent terminals can be used to simplify and eliminate multiple penetrations in the building structure (refer to the Venting Section). The exhaust vent and intake piping lengths, routing and termination methods must all comply with the methods and limits given in the Venting section, Part 5 of this manual.

When installing a combustion air intake from outdoors, care must be taken to utilize uncontaminated combustion air. **To prevent** combustion air contamination, see Table 1: Contaminant Table.

2. INDOOR COMBUSTION AIR INSTALLATION IN CONFINED OR UNCONFINED SPACE

This heater requires fresh, uncontaminated air for safe operation and must be installed in a mechanical room where there is adequate combustion and ventilating air. **NOTE: To prevent combustion air contamination**, see Table 1: Contaminant Table.

Combustion air from the indoor space can be used if the space has adequate area or when air is provided through a duct or louver to supply sufficient combustion air based on the water heater input. **Never obstruct the supply of combustion air to the water heater.** If the water heater is installed in areas where indoor air is contaminated (see Table 1) it is imperative that the water heater be installed as direct vent so that all combustion air is taken directly from the outdoors into the water heater intake connection.

Unconfined space is space with volume greater than 50 cubic feet per 1,000 Btu/hour (4.8 cubic meters per kW) of the total input rating of all fuel-burning appliances installed in that space. Rooms connected directly to this space, through openings not furnished with doors, are considered part of the space. See **Figure**, p. 36 for details.

Confined space is space with volume less than 50 cubic feet per 1,000 Btu/hour (4.8 cubic meters per kW) of the total input rating of all fuel-burning appliances installed in that space. Rooms connected directly to this space, through openings not furnished with doors, are considered part of the space.

When drawing combustion air from inside a conventionally constructed building to a confined space, such space should be provided with two permanent openings: one located 6" (15 cm) below the space ceiling, the other 6" (15 cm) above the space floor. Each opening should have a free area of one square inch per 1,000 Btu/hr ($22 \text{ cm}^2/\text{kW}$) of the total input of all appliances in the space, but not less than 100 square inches (645 cm^2).

If the confined space is within a building of tight construction, air for combustion must be obtained from the outdoors as outlined in the Venting section, Part 5 of this manual.

CAUTION

When drawing combustion air from the outside into the mechanical room, care must be taken to provide adequate freeze protection.

A WARNING

Do not attempt to vent this water heater by any means other than those described in this manual. Doing so will void the warranty, and may result in severe personal injury or death.

A WARNING

Failure to provide an adequate supply of fresh combustion air can cause poisonous flue gases to enter living space, resulting in severe personal injury or death. To prevent combustion air contamination, see Table 1.

F. PREVENT COMBUSTION AIR CONTAMINATION

Install intake piping for the heater as described in the Venting Section. Do not terminate exhaust in locations that can allow contamination of intake air.

🕰 WARNING

Ensure that the intake air will not contain any of the contaminants below. Contaminated air will damage the heater, resulting in possible substantial property damage, severe personal injury, or death. For example, do not pipe intake near a swimming pool. Also, avoid areas subject to exhaust fumes from laundry facilities. These areas always contain contaminants.

Dry cleaning/laundry areas and establishments Swimming pools Aetal fabrication plants
Metal fabrication plants
Beauty shops
Refrigeration repair shops
Photo processing plants
Auto body shops
Plastic manufacturing plants
Furniture refinishing areas and establishments
New building construction
Remodeling areas
Garages and workshops

Table 1: Contaminant Table

NOTE: DAMAGE TO THE HEATER CAUSED BY EXPOSURE TO CORROSIVE VAPORS IS NOT COVERED BY WARRANTY. (Refer to the limited warranty for complete terms and conditions).

G. REMOVING A HEATER FROM A COMMON VENT SYSTEM

🕼 DANGER

Do not install the heater into a common vent with any other appliance. This will cause flue gas spillage or appliance malfunction, resulting in possible substantial property damage, severe personal injury, or death.

A WARNING

Failure to follow all instructions can result in flue gas spillage and carbon monoxide emissions, causing severe personal injury or death.

When removing an existing heater, follow the steps below.

1. Seal any unused openings in the common venting system.

2. Visually inspect the venting system for proper size and horizontal pitch to determine if there is blockage, leakage, corrosion or other deficiencies that could cause an unsafe condition.

3. If practical, close all building doors, windows and doors between the space in which the water heater remains connected to the common venting system and other spaces in the building. Turn on clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, at maximum speed. Do not operate a summer exhaust fan. Close all fireplace dampers.

4. Place in operation the appliance being inspected. Follow the lighting instructions. Adjust the thermostat so the appliance will operate continuously.

5. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.



Figure 2: CO Warning Label

6. After it has been determined that each appliance remaining connected to common venting system properly vents when tested as outlined, return doors, windows, exhaust fans, fireplace dampers and any other gas burning appliance to their previous condition of use.

7. Any improper operation of the common venting system should be corrected to conform to the National Fuel Gas Code, ANSI Z223.1. When resizing any portion of the common venting system, the system should approach the minimum size as determined using the appropriate tables in Appendix G in the National Fuel Gas Code, ANSI Z 223.1.

H. WATER CHEMISTRY

CAUTION

Chemical imbalance of the water supply may affect efficiency and cause severe damage to the water heater and associated equipment. GIANT recommends having water quality professionally analyzed to determine whether it is necessary to install a water softener. It is important that the water chemistry on both the domestic hot water and central heating sides are checked before installing the water heater, as water quality will affect the reliability of the system. Failure of a heat exchanger due to lime scale build-up on the heating surface, low pH, or other chemical imbalance IS NOT covered by the warranty.

CAUTION

Operating temperatures above 135°F (57°C) will further accelerate the build-up of lime scale on the heating surface and may shorten the service life of the water heater. Failure of a heat exchanger due to lime scale build-up on the heating surface, low pH, or other chemical imbalance IS NOT covered by the warranty.

Outlined below are water quality parameters which need to be met in order for the system to operate efficiently for many years.

Water Hardness

Water hardness is mainly due to the presence of calcium and magnesium salts dissolved in water. The concentration of these salts is expressed in mg/L, ppm, or grains per gallon as a measure of relative water hardness. "Grains per gallon" is the common reference measurement used in the U.S. water heater industry. Hardness expressed as mg/L or ppm may be divided by 17.1 to convert to grains per gallon. Water may be classified as very soft, slightly hard, moderately hard, or hard based on its hardness number. The minerals in the water precipitate out as the water is heated and cause accelerated lime scale accumulation on a heat transfer surface. This lime scale build-up may result in premature failure of the heat exchanger. Operating temperatures above 135°F (57°C) will further accelerate the build-up of lime scale on the heating surface and may shorten the service life of the water heater.

Water that is classified as hard and very hard must be softened to avoid heat exchanger failure. See below for further information about water hardness.

CLASSIFICATION	MG/L OR PPM	GRAINS/GAL
Soft	0 – 17.1	0 - 1
Slightly Hard	17.1 – 60	1 – 3.5
Moderately Hard	60 - 120	3.5 - 7.0
Hard	120 – 180	7.0 – 10.5
Very Hard	180 and over	10.5 and over

If the hardness of the water exceeds the maximum level of 7 grains per gallon, water should be softened to a hardness level no lower than 5 grains per gallon. Water softened as low as 0 to 1 grain per gallon may be under-saturated with respect to calcium carbonate, resulting in water that is aggressive and corrosive.

pH of Water

pH is a measure of relative acidity, neutrality or alkalinity. Dissolved minerals and gases affect water pH. The pH scale ranges from 0 to 14. Water with a pH of 7.0 is considered neutral. Water with a pH lower than 7 is considered acidic. Water pH higher than 7 is considered alkaline. A neutral pH (around 7) is desirable for most potable water applications. Corrosion damage and heater failures resulting from water pH levels of lower than 6 or higher than 8 ARE NOT covered by the warranty. The ideal pH range for water used in a storage tank or a water heater system is 7.2 to 7.8.


Total Dissolved Solids

Total Dissolved Solids (TDS) is a measurement of all minerals and solids dissolved in a water sample. The concentration of total dissolved solids is usually expressed in parts per million (ppm).

Water with a high TDS concentration will greatly accelerate lime and scale formation in the hot water system. Most high TDS concentrations precipitate out of the water when heated. This can generate a scale accumulation on the heat transfer surface that will greatly reduce the service life of a water heater. This scale accumulation can also impede the ability of the heat exchanger to transfer heat into the water. A heat exchanger damaged or blocked by lime/scale accumulation must be replaced.

The manufacturer of the water heater has no control of water quality, especially TDS levels in your system. Total dissolved solids in excess of 2,000 ppm will accelerate lime and scale formation in the heat exchanger. Heat exchanger failure due to total dissolved solids in excess of 2,000 ppm is a non-warrantable condition. Failure of a water heater due to lime scale build up on the heating surface IS NOT covered by the warranty.

Hardness: 7 grains Chloride levels: 100 ppm pH levels: 6-8 TDS: 2,000 ppm Sodium: 20 MGL



PHOENIX WATER HEATER AND SANITIZER BOOSTER DIMENSIONS													
MODEL*	GAL.	А	В	С	D	E	F	G	Н	J	K	L	М
PH100-55/130-55/160-55/199-55	55	23"	52"	45"	5"	14-3/4"	16-1/4"	5-1/4"	1"	45"	34-1/4"	45"	27-1/2"
PH100-80/130-80/160-80/199-80	80	23"	72"	64"	5-3/4"	17"	181-/2"	7-3/4"	3-1/4"	64"	34-1/4"	64"	29-3/4"
PH100-119/130-119/160-119/199-119	119	27"	74"	66-1/4"	7-1/2"	18-3/4"	21-1/2"	10-1/2"	5"	66-1/2"	38-1/2"	66-1/2"	31"
PH130-55SA / PH199-55SA	55	23"	52"	45"	5"	14-3/4"	16-1/4"	5-1/4"	1"	45"	34-1/4"	45"	27-1/2"

	PH	OENIX WAT	FER HEATE	R SPECI	FICATI	ONS		
MODEL*	INPUT MODULATION	AIR INTAKE/ EXHAUST VENT SIZE	INLET/ OUTLET SIZE	AUXILIARY CONN.	GAS LINE CONN.	SYSTEM RELIEF PIPE SIZE	Shipping Weight	MAX. TEMPERATURE LIMIT
PH100-55	35,000 - 100,000	2"	1" NPT	1" FNPT	3/4"	3/4"	175 LBS.	160°
PH130-55	35,000 - 130,000	2"	1" NPT	1" FNPT	3/4"	3/4"	175 LBS	160°
PH160-55	40,000 - 160,000	3"	1" NPT	1" FNPT	3/4"	3/4"	175 LBS.	160°
PH199-55	40,000 - 199,000	3"	1" NPT	1" FNPT	3/4"	3/4"	175 LBS	160°
PH100-80	35,000 - 100,000	2"	1-1/2" NPT	1" FNPT	3/4"	3/4"	235 LBS.	160°
PH130-80	35,000 - 130,000	2"	1-1/2" NPT	1" FNPT	3/4"	3/4"	235 LBS	160°
PH160-80	40,000 - 160,000	3"	1-1/2" NPT	1" FNPT	3/4"	3/4"	235 LBS.	160°
PH199-80	40,000 - 199,000	3"	1-1/2" NPT	1" FNPT	3/4"	3/4"	235 LBS.	160°
PH100-119	35,000 - 100,000	2"	1-1/2" NPT	1" FNPT	3/4"	3/4"	405 LBS.	160°
PH130-119	35,000 - 130,000	2"	1-1/2" NPT	1" FNPT	3/4"	3/4"	405 LBS.	160°
PH160-119	40,000 - 160,000	3"	1-1/2" NPT	1" FNPT	3/4"	3/4"	405 LBS.	160°
PH199-119	40,000 - 199,000	3"	1-1/2" NPT	1" FNPT	3/4"	3/4"	405 LBS.	160°
	PHOENIX SANITIZER BOOSTER SPECIFICATIONS							
PH130-55SA	35,000 - 130,000	2"	1" NPT	1" FNPT	3/4"	3/4	175 LBS	184°
PH-199-55SA	40,000 - 199,000	3"	1"	1" FNPT	3/4"	3/4	175 LBS	184°

Figure 3 – *All dimensions are approximate – A suffix of "LP" denotes propane gas - LP-179-B

A WARNING

UNCRATING HEATER – Any claims for damage or shortage in shipment must be filed immediately against the transportation company by the consignee.

A CAUTION

COLD WEATHER HANDLING – If the heater has been stored in a very cold location (BELOW 0°F (-18°C)) before installation, handle with care until the plastic components come to room temperature.

PERFORMANCE SPECIFICATIONS FOR PHOENIX MODELS													
		Temperature Rise											
BTU/HR	Efficiency	(°F)	40	50	60	70	80	90	100	110	120	130	140
		(°C)	22	28	33	39	44	50	56	61	67	72	78
		GPH	298	240	202	173	152	136	123	110	101	94	88
100,000	96%	GPM	5	4	3.4	2.9	2.5	2.25	2	1.8	1.7	1.6	1.5
100,000	90 %	LPH	1128	908	765	655	575	515	466	416	382	356	333
		LPM	18.8	15.1	12.75	10.9	9.6	8.6	7.8	6.9	6.4	5.9	5.6
		GPH	384	309	260	222	195	175	158	141	130	120	112
130,000	96%	GPM	6.4	5.2	4.3	3.7	3.25	2.9	2.6	2.4	2.2	2	1.9
130,000	90 %	LPH	1454	1170	984	840	738	662	598	534	492	454	424
		LPM	24.25	19.5	16.4	14	12.3	11	10	8.9	8.2	7.6	7
		GPH	470	378	317	271	238	213	192	173	159	147	137
160,000	96%	GPM	7.8	6.3	5.3	4.5	4	3.6	3.2	2.9	2.7	2.5	2.3
100,000	90%	LPH	1779	1431	1200	1026	901	806	727	655	602	556	519
		LPM	29.7	23.9	20	17.1	15	13.4	12.1	10.9	10	9.3	8.7
		GPH	582	468	392	335	294	263	237	213	196	181	169
100.000	96%	GPM	9.7	7.8	6.5	5.6	4.9	4.4	4	3.6	3.3	3	2.8
199,000	50%	LPH	2203	1772	1484	1268	1113	996	897	806	742	685	640
		LPM	36.7	29.5	24.7	21.1	18.6	16.6	15	13.4	12.4	11.4	10.7

Remove all sides of the shipping crate to allow the heater to be lifted into its installation location.

Table 2: Recovery on rating plate is based at 94% thermal efficiency at 70°F (39°C) rise, as required by ANSI

PERFORMANCE EQUATIONS

GPM = Temp Rise (°F) x 500

GPH = GPM x 60

PART 4 – HEATER PIPING

Failure to follow the instructions in this section WILL VOID the warranty and may result in property damage, serious injury, or death.

A CAUTION

Never use dielectric unions or galvanized steel fittings when connecting to a stainless steel storage tank or heater. Use only copper or brass fittings. Teflon thread sealant must be used on all connections.

A. GENERAL PIPING INFORMATION

CAUTION

Use two (2) wrenches when tightening water piping at heater. Use one wrench to prevent the heater return or supply line from turning. Failure to prevent piping connections from turning could cause damage to heater components.

CAUTION

The heater control module uses temperature sensors to provide both high limit protection and modulating temperature control. The control module also provides low water protection by sensing the water level in the tank. Some codes/jurisdictions may require additional external controls.

B. SCALDING

APPROXIMATE	APPROXIMATE TIME / TEMPERATURE RELATIONSHIPS IN SCALDS							
120°F (49°C)	More than 5 minutes							
125°F (52°C)	1 ½ to 2 minutes							
130°F (54°C)	About 30 seconds							
135°F (57°C)	About 10 seconds							
140°F (60°C)	Less than 5 seconds							
145°F (63°C)	Less than 3 seconds							
150°F (66°C)	About 1 ½ seconds							
155°F (68°C)	About 1 second							

Table 3

This heater can deliver scalding water. Be careful whenever using hot water to avoid scalding injury. Certain appliances, such as dishwashers and automatic clothes washers may require increased water temperature. By setting the thermostat on this heater to obtain the increased water temperature required by these appliances, you may create the potential for scald injury.

To protect against injury, you should install a mixing valve in the water system. This valve will reduce point of discharge temperature by mixing cold and hot water in branch supply lines. Such valves are available from your local plumbing supplier.

Table 3 details the relationship of water temperature and time with regard to scald injury and may be used as a guide in determining the safest water temperature for your applications.

C. TEMPERATURE AND PRESSURE RELIEF VALVE

🛦 WARNING

To avoid water damage or scalding due to relief valve operation:

- Discharge line must be connected to relief valve outlet and run to a safe place of disposal. Terminate the discharge line in a manner that will prevent possibility of severe burns or property damage should the relief valve discharge.
- Discharge line must be as short as possible and the same size as the valve discharge connection throughout its entire length.
- Discharge line must pitch downward from the valve and terminate at least 6" (15 cm) above the floor drain, making discharge clearly visible.
- The discharge line shall terminate plain, not threaded, with a material serviceable for temperatures of 375°F (191°C) or greater.
- Do not pipe discharge to any location where freezing could occur.
- No shutoff valve may be installed between the relief valve and heater or in the discharge line. Do not plug or place any obstruction in the discharge line.
- Test the operation of the relief valve after filling and pressurizing the system by lifting the lever. Make sure the valve discharges freely. If the valve fails to operate correctly, immediately replace with a new properly rated relief valve.
- Test T&P value at least once annually to ensure the waterway is clear. If value does not operate, turn the heater "off" and call a plumber immediately.
- Take care whenever operating relief valve to avoid scalding injury or property damage.

FAILURE TO COMPLY WITH THE ABOVE GUIDELINES COULD RESULT IN FAILURE OF RELIEF VALVE OPERATION, RESULTING IN POSSIBILITY OF SUBSTANTIAL PROPERTY DAMAGE, SEVERE PERSONAL INJURY, OR DEATH.

🛦 WARNING

Do not thread a cap or plug into the relief valve under any circumstances! Explosion and property damage, serious injury, or death may result.

D. BACKFLOW PREVENTER

Use a backflow preventer specifically designed for water heater installations. This valve should be installed on the cold water fill supply line per local codes.

E. POTABLE EXPANSION TANK

A potable hot water expansion tank is required to offset heated water expansion. In most city plumbing systems, the water meter has a no return or back flow device built into the system to prevent back flowing of water into city mains. Some local codes require back flow preventers on all incoming water supplies. The hot water expansion tank must be listed for potable water use. The expansion tank should be located on the cold inlet piping close to the water heater.

16

🛕 D A N G E R



Water temperature over 125°F can cause severe burns instantly or death from scalds. Children, disabled and elderly are at highest risk of being scalded.

See instruction manual before setting temperature at water heater.

Feel water before bathing or showering.

Temperature limiting valves are available, see manual.

EXPANSION TANK AND MAKE-UP WATER

1. Ensure that the expansion tank is sized to correctly handle heater and system water volume and temperature.

CAUTION

Undersized expansion tanks cause system water to be lost from the relief valve, causing make-up water to be added. Eventual heater failure can result due to excessive make-up water addition. SUCH FAILURE IS NOT COVERED BY WARRANTY.

2. The expansion tank must be located as shown in the Heater Piping Details, or following recognized design methods. See expansion tank manufacturer's instructions for details.

The expansion tank must be suitable for hot potable water.

F. WATER PIPING

A CAUTION

Never use dielectric unions or galvanized steel fittings on any domestic water or auxiliary connections. Use only copper or brass fittings. Thread sealant must be used on all connections.

The domestic water connections must be installed in accordance to all local and national plumbing codes, or any applicable standard which prevails. The inlet and outlet ports are 1" (2.5 cm) on 55 gallon (208 L) models, and 1 ½" (3.8 cm) on 80 (303 L) and 119 gallon (451 L) models.

On the cold inlet, install a 1" (2.5 cm) brass tee on 55 gallon (208 L) models, or a 1 $\frac{1}{2}$ " (3.8 cm) tee on 80 (303 L) and 119 gallon (451 L) models. On the run of the 1" (2.5 cm) brass tee, install a brass drain cock or equivalent with pipe sealant compound. In the branch of the 1" (2.5 cm) or a 1 $\frac{1}{2}$ " (3.8 cm) brass tee, install a copper male adapter to match your copper plumbing system. For convenience, you may install a sweat shut off valve and a union in the cold inlet piping to ease future servicing. If there is a back flow preventer or any type of a no return valve in the system, you must install an additional tee here, suitable for a potable hot water expansion tank.

In the hot outlet, install a suitable adapter to match the copper tubing of the plumbing system. A thermal trap or heat trap loop may be installed here to provide additional energy savings and prevent the thermal siphoning of domestic hot water.

G. AUXILIARY CONNECTIONS

The auxiliary connections are additional connections for air handlers, plate exchangers, or other devices that supply hot water. These connections must be installed in accordance with all local and national codes or any applicable standard that prevails. Auxiliary connections are 1" (2.5 cm) on all models. Never use dielectric unions or galvanized steel fittings. Use only copper or brass fittings. Sealant must be used on all connections. The top port is the supply outlet and the bottom port is the return inlet.

Never connect auxiliary connections to any system that uses glycol or other solutions formulated for hydronic systems. These auxiliary connections are to be used only in a potable water system. Failure to follow this warning could result in serious injury or death.

H. PIPING DIAGRAM




Figure 4: Phoenix With Air Handler

NOTES:

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.

4. All circulators should have an integral flow check.

5. Check with air handler manufacturer for proper sizing.

6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.

NOTES FOR AIR HANDLER APPLICATION:

1. ALL WATER PIPING MUST BE INSULATED.

2. YOU MUST INSTALL A VACUUM RELIEF VALVE PER 248 CMR.

NOTE: THIS DRAWING IS MEANT TO DEMONSTRATE SYSTEM PIPING ONLY. THE INSTALLER IS RESPONSIBLE FOR ALL EQUIPMENT AND DETAILING REQUIRED BY LOCAL CODES.

\Lambda DANGER

An ASSE 1017 thermostatic mixing valve <u>MUST</u> be installed when using outdoor reset. Failure to do so could result in substantial property damage, serious injury, or death.




Figure 5: Phoenix with Air Handler on Side

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.

4. All circulators should have an integral flow check.

5. Check with air handler manufacturer for proper sizing.

6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.

NOTES FOR AIR HANDLER APPLICATION:

1. ALL WATER PIPING MUST BE INSULATED.

2. YOU MUST INSTALL A VACUUM RELIEF VALVE PER 248 CMR.

NOTE: THIS DRAWING IS MEANT TO DEMONSTRATE SYSTEM PIPING ONLY. THE INSTALLER IS RESPONSIBLE FOR ALL EQUIPMENT AND DETAILING REQUIRED BY LOCAL CODES.

A DANGER

An ASSE 1017 thermostatic mixing valve <u>MUST</u> be installed when using outdoor reset. Failure to do so could result in substantial property damage, serious injury, or death.




Figure 6: Reverse Manifold and Piping Diagram for Phoenix - LP-179-N

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.

4. All circulators should have an integral flow check.

5. Check with air handler manufacturer for proper sizing.

6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.




Figure 7: Closed Loop with Radiant Heating - LP-179-U

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.

4. All circulators should have an integral flow check.

5. Check with brazed plate manufacturer for correct plate connections and orientation.

6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.




Figure 8: Phoenix With Storage Tank

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

- 3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.
- 4. All circulators should have an integral flow check.
- 5. Drains and check valve between unit and storage tank will assist in purging air from system.
- 6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.




Figure 9: Phoenix with Recirculation Line and Thermostatic Mixing Valve Piping

1. Minimum pipe size should match unit connection size. Upsize pipe accordingly if greater flow is required.

2. A thermal expansion tank suitable for potable water must be sized and installed within this piping system between the backflow preventer and the cold water inlet.

3. Gas line must be rated to the unit maximum input capacity. Unit must have 10' (3 m) of pipe after gas regulator.

4. All circulators should have an integral flow check.

5. Drains and check valve between unit and storage tank will assist in purging air from system.

6. This drawing is meant to demonstrate system piping only. The installer is responsible for all equipment and detailing required by local codes.

A DANGER

An ASSE 1017 thermostatic mixing valve <u>MUST</u> be installed when using outdoor reset. Failure to do so could result in substantial property damage, serious injury, or death.

PART 5 – VENTING, COMBUSTION AIR AND CONDENSATE REMOVAL

\Lambda DANGER

The heater must be vented as detailed in this Venting Section. Ensure exhaust vent and intake piping complies with these instructions regarding vent system. Inspect finished exhaust vent and intake piping thoroughly to ensure all joints are well secured, airtight, and comply with all applicable code requirements, as well as with the instructions provided in this manual. Failure to properly install the vent system will result in severe personal injury or death.

<u>A. GENERAL</u>

A DANGER

This heater is certified as a "Category IV" appliance, and requires a special venting system. The vent system will operate with a positive pressure in the pipe. Exhaust gases must be piped directly outdoors using the vent materials and rules outlined in these instructions. Do not connect vent connectors serving appliances vented by natural draft into any portion of mechanical draft systems operating under positive pressure. Follow the venting instructions below carefully. Failure to do so will result in substantial property damage, severe personal injury, or death.

1. Installation should be made in accordance with the regulations of the Authority Having Jurisdiction, local code authorities, and utility companies which pertain to this type of water heating equipment.

2. Install the venting system in accordance with these instructions and with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, CAN/CGA B149, and/or applicable provisions of local building codes.

3. This water heater must be vented with materials, components, and systems listed and approved for Category IV appliances.

A DANGER

Exhaust vent and intake pipes are to be piped separately. This heater cannot share a common exhaust or intake with multiple appliances. Failure to follow this instruction will result in substantial property damage, severe personal injury, or death.

NOTE: To avoid contamination often contained in indoor air, it is best to pipe all intake combustion air directly to the outdoors.

NOTE: If exhaust vent pipe system passes through an unheated space, such as an alcove or attic, the space must be heated or the pipe must be insulated. The insulation must have an R value sufficient to prevent freezing of the condensate.

Improper seating of vent pipe gaskets can cause eventual gasket failure and exhaust gas leakage. Ensure the exhaust vent pipe is properly beveled and seated before insertion into the flue adapter. Failure to do so could result in property damage, severe personal injury, or death.

A DANGER

Due to the extreme flammability of most glue, cements, solvents, and primers used to join plastic exhaust vent and intake pipes, explosive solvent vapors must be cleared from all vent piping before start-up. Avoid using excess cement or primer, as this may pool in the vent pipes. Vent assemblies should be allowed to cure for a period of at least eight (8) hours before powering a connected appliance. Failure to follow these instructions will result in substantial property damage, severe personal injury, or death. It is the installers' responsibility to understand the hazards associated with explosive solvents and take the necessary precautions to avoid these risks.

B. APPROVED MATERIALS FOR EXHAUST VENT AND INTAKE PIPE

APPROVED EXHAUST VENT AND INTAKE PIPE MATERIAL							
ltem	Material	Standards for Installation in:					
nem	Wateria	United States	Canada				
	PVC schedule 40/80	ANSI/ASTM D1785	PP, CPVC, and PVC venting				
	PVC-DWV*	ANSI/ASTM D2665	must be ULC-S636 Certified.				
Exhaust vent or Intake pipe and fittings	CPVC schedule 40/80	ANSI/ASTM F441	IPEX is an approved				
	Polypropylene	ULCS636	manufacturer in Canada, supplying vent material listed to ULC-S636.				
	Stainless Steel AL29-4C	Certified for Category IV and direct vent appliance venting	Certified for Category IV and direct vent appliance venting				
Bing comont/primor	PVC	ANSI/ASTM D2564	IPEX System 636 Cements &				
Pipe cement/primer	CPVC	ANSI/ASTM F493	Primers				

Table 4

DANGER Λ

- The exhaust and intake components installed with this heater must be used for near heater piping BEFORE transitioning to the . approved materials listed above. DO NOT REMOVE these installed components. Doing so WILL VOID heater warranty.
- PVC/CPVC pipe and fittings of the same diameter are considered interchangeable.
- DO NOT use Foam Core Pipe in any portion of the exhaust piping from this water heater.
- DO NOT connect PVC/CPVC to PP without an approved vent connector.
- When installing AL29-4C vent piping, install a PVC-to-stainless adapter at the heater vent connection, and at the termination when using an GIANT PVC termination kit. DO NOT mix AL-29-4C piping from different manufacturers unless using adapters specifically designed for the purpose by the manufacturer.
- *PVC-DWV for air intake applications ONLY.

Failure to follow these directions will result in substantial property damage, severe personal injury, or death.

A WARNING

DO NOT mix components from different venting systems. The vent system could fail, causing leakage of flue products into the living space. Use only the approved pipe and fitting materials, and primer and cement specifically designed for the material used, as listed in Table 4. Failure to do so could result in property damage, severe personal injury, or death.

A WARNING

Exhaust vent adaptors are not designed as load-bearing devices, and must not be used to support exhaust vent piping. All vent pipes must be properly connected, supported, and the exhaust must be pitched a minimum of ¼" (6.3 mm) per foot back to the heater to allow drainage of condensate. Failure to properly support vent piping and follow the information in this statement could result in product damage, severe personal injury, or death.

NOTE: The use of double-wall vent or insulated material for the combustion air inlet pipe is recommended in cold climates to prevent the condensation of airborne moisture in the incoming combustion air.

C. REQUIREMENTS FOR INSTALLATION IN CANADA

1. Installations must be made with a vent pipe system certified to ULC-S636. IPEX is an approved vent manufacturer in Canada supplying vent material listed to ULC-S636. Additionally you may use AL29-4C stainless steel venting to comply with Canadian requirements.

2. The first three (3) feet (91 cm) of vent pipe from the water heater flue outlet must be readily accessible for visual inspection.

3. The components of the certified vent system must not be interchanged with other vent systems or unlisted pipe / fittings.

Cellular foam core piping may be used on air inlet piping **only**.

DANGER

You must not use "B" vent in an exhaust application. "B" vent is for intake applications ONLY. Using "B" vent in an exhaust application will result in serious injury or death.

D. EXHAUST VENT AND INTAKE PIPE LOCATION

1. DETERMINE EXHAUST VENT LOCATION

a. The vent piping for this water heater is approved for zero clearance to combustible construction.


b. See illustration within this section of clearances for location of exit terminals of direct-vent venting systems.

c. This water heater vent system shall terminate at least three (3) feet (91 cm) above any forced air intake located within ten (10) feet (3 m). Note: this does not apply to the combustion air intake of a direct-vent appliance.

Breathing Hazard - Carbon Monoxide Gas · Do not operate heater if flood damaged. Install vent system in accordance with local codes and manufacturers installation instructions. Do not obstruct heater air intake or exhaust. Support all vent piping per manufacturers installation instructions. Do not place chemical vapor emitting products near unit. According to NFPA 720, carbon monoxide detectors should be installed outside each sleeping area. Never operate the heater unless it is vented to the outdoors. Analyze the entire vent system to make sure that condensate will not become trapped in a section of vent pipe and therefore reduce the open cross sectional area of the vent. Breathing carbon monoxide can cause brain damage or death

d. Provide a minimum of one (1) foot (30 cm) distance from any door, operable window, or gravity intake into any building. e. Provide a minimum of one (1) foot (30 cm) clearance from the bottom of the exhaust above the expected snow accumulation level. Snow removal may be necessary to maintain clearance.

f. Provide four (4) feet (1.2 m) horizontal clearance from electrical meters, gas meters, gas regulators, relief equipment, exhaust fans and inlets. In no case shall the exit terminal be above or below the aforementioned equipment unless the four (4) feet (1.2 m) horizontal distance is maintained.



- g. When adjacent to a public walkway, locate exit terminal at least seven (7) feet (2.1 m) above grade.
- h. Do not locate the exhaust directly under roof overhangs to prevent icicles from forming.

i. Provide four (4) feet (1.2 m) clearance from the inside corner of vertical walls, chimneys, etc., as well as horizontal corners created by roof overhangs.

2. DETERMINE INTAKE PIPE LOCATION

a. Provide one (1) foot (30 cm) clearance from the bottom of the intake pipe and the level of maximum snow accumulation. Snow removal may be necessary to maintain clearances.

b. Do not locate intake pipe in a parking area where machinery may damage the pipe.

c. When venting with a two pipe system, maximum distance between exhaust vent and intake pipe is six (6) feet (1.8 m). Minimum distance between exhaust vent and intake pipe on single water heater is 10" (25 cm) center-to-center. Minimum distance between exhaust vents and intake pipes on multiple water heaters is 10" (25 cm) center-to-center.

NOTE: Due to potential moisture build-up, sidewall venting may not be the preferred venting option. Carefully consider venting installation and location to save time and cost.

A WARNING

The building owner is responsible for keeping the exhaust and intake terminations free of snow, ice, or other potential blockages, as well as scheduling routine maintenance. Failure to keep the vent piping terminations clear and properly maintain the heater could result in property damage, severe personal injury, or death.

For each floor containing bedroom(s), a carbon monoxide detector and alarm shall be placed in the living area outside the bedrooms, as well as in the room that houses the heater. Detectors and alarms shall comply with NFPA 720 (latest edition). Failure to comply with requirements for detectors and alarms could result in property damage, severe personal injury, or death.




Figure 10: Venting

E. EXHAUST VENT AND INTAKE PIPE SIZING

1. The exhaust vent and intake pipe size is 2" (5 cm) for the PH100 and PH130 and 3" (7.6 cm) for the PH160 and PH199.

2. The maximum total equivalent length of 2" (5 cm) exhaust vent and intake pipe **must not exceed 85 feet (26 m)**. The total maximum equivalent length of 3" (7.6 cm) exhaust vent and intake pipe **must not exceed 200 feet (61 m)**.

a. The equivalent length of elbows, tees, and other fittings are listed in the Friction Loss Table, Table 5:

FRICTION LOSS EQUIVALENT IN PIPING AND FITTINGS								
FITTINGS OR PIPING	EQUIVALENT FEET							
FITTINGS OK FIFING	2" (5 cm)	3" (7.6 cm)	4" (10 cm)					
90 DEGREE ELBOW*	5' (1.5 m)	5' (1.5 m)	3' (91 cm)					
45 DEGREE ELBOW	3' (91 cm)	3' (91 cm)	1' (30 cm)					
COUPLING	0'	0'	0'					
AIR INLET TEE	0'	0'	0'					
STRAIGHT PIPE	1' (30 cm)	1' (30 cm)	1' (30 cm)					
CONCENTRIC VENT KIT	3' (91 cm)	3' (91 cm)	N/A					
V500 2" (5 cm) VENT KIT	1' (30 cm)	N/A	N/A					
V1000 3" (7.6 cm) VENT KIT	N/A	1' (30 cm)	1' (30 cm)					
V2000 4" (10 cm) VENT KIT	N/A	1' (30 cm)	1' (30 cm)					

Table 5 - *Friction loss for long radius elbow is one (1) foot (30 cm) less. NOTE: Consult Polypropylene venting instructions for friction loss and pressure drop equivalents.

b. For example: If the exhaust vent has two (2) 90° elbows and ten (10) feet (3 m) of PVC pipe we will calculate:

Exhaust Vent Equivalent Length = (2x5) + 10 = 20 feet (6 m).

Further, if the intake pipe has two (2) 90° elbows, one (1) 45° elbow and ten (10) feet (3 m) of PVC pipe, the following calculation applies:

Intake Pipe Equivalent Length = (2x5) + 3 + 10 = 23 feet (7 m).

Finally, if a concentric vent kit is used we find:

Total Equivalent Length = 20 + 23 + 3 = 46 feet (14 m).

The total equivalent length is 46 feet (14 m) which is well below the maximum of 85 feet (26 m).

3. The minimum total equivalent length is 16 equivalent feet (5 m).

CAUTION

Failure to provide a minimum total vent length of 16 equivalent feet (5 m) could result in property damage and improper product operation.

F. LONGER VENT RUNS

The maximum total equivalent length can be extended by increasing the diameter of both exhaust vent and intake pipe equally. However, the transitions should begin a minimum of 15 total equivalent feet (4.6 m) from the water heater.

a. The maximum total equivalent length for increased diameter vent pipes is 125 feet (38 m) for 2" (5 cm) transitioning to 3" (7.6 cm) pipe (this number includes the minimum 15 total equivalent feet (4.6 m) necessary for transition), and 200 maximum total equivalent feet (61 m) for 3" (7.6 cm) transitioning to 4" (10 cm) pipe (including the minimum 15 total equivalent feet (4.6 m) necessary for transition).

b. Transitions should always be made in vertical sections of pipe to prevent the condensate from pooling in the vent pipe.

MODEL	MAXIMUM TOTAL EQUIVALENT LENGTH AT STANDARD VENT CONNECTION	REDUCING COUPLING	MAXIMUM TOTAL EQUIVALENT LENGTH AT MAXIMUM INCREASED VENT SIZE
PH100 PH130	85' (26 m) @ 2" (5 cm)	3" (7.6 cm) X 2" (5 cm)	125' (38 m) at 3" (7.6 cm)
PH160 PH199	200' (61 m) @ 3" (7.6 cm)	4" (10 cm) X 3" (7.6 cm)	200' (61 m) at 4" (10 cm)

Table 6: Vent Sizing – Diameter and Length

c. If the transition occurs at a distance greater than 15 equivalent feet (4.6 m) from the water appliance, the maximum equivalent length will be reduced.

A DANGER

Total maximum equivalent length of increased diameter exhaust vent and intake pipe must not exceed the lengths defined in this manual. 125 maximum total equivalent feet (38 m) for 2" (5 cm) increased to 3" (7.6 cm) diameter vent pipe; 200 maximum total equivalent feet (61 m) for 3" (7.6 cm) increased to 4" (10 cm) diameter vent pipe. Failure to keep the total equivalent length below the maximum lengths determined in this manual will result in faulty appliance operation, substantial property damage, serious personal injury, or death.

TRANSITION POINT (FT. FROM WATER APPLIANCE)	TEL OF OVERSIZED VENT PIPE (FT.)*	MAXIMUM <u>TEL</u> OF ALL VENT PIPE (FT.)
15 (4.6 m)	95 (29.0 m)	125 (38.0 m)
20 (6.0 m)	77.5 (23.6 m)	117.5 (35.8 m)
25 (7.6 m)	60.5 (18.4 m)	110.5 (33.7 m)
30 (9.1 m)	43 (13.1 m)	103 (31.4 m)
35 (10.7 m)	26 (7.9 m)	96 (29.3 m)
40 (12.2 m)	8.5 (2.6 m)	88.5 (27.0 m)
NONE	0	85 (26.0 m)

Table 7 – TEL = Total Equivalent Length *Oversized vent pipe diameter is 1" (2.5 cm) or greater than factory supplied connection.

G. EXHAUST VENT AND INTAKE PIPE INSTALLATION

🏠 WARNING

All joints of positive pressure vent systems must be sealed completely to prevent leakage of flue products into living space.

- Use only solid PVC or CPVC pipe or a Polypropylene vent system approved for use with Category IV appliances. FOAM CORE PIPING IS NOT APPROVED FOR EXHAUST VENT APPLICATIONS. Foam core piping may be used on air inlet piping only.
- 2. Remove all burrs and debris from joints and fittings.
- 3. When using PVC or CPVC pipe, all joints must be properly cleaned, primed, and cemented. Use only cement and primer approved for use with the pipe material. Cement must conform to ASTM D2564 for PVC and ASTM F493 for CPVC pipe. **NOTE: DO NOT CEMENT POLYPROPYLENE PIPE.**
- 4. Ensure the vent is located where it will not be exposed to prevailing winds.
- 5. In all roof venting applications, exhaust discharge must point away from the pitch of the roof.
- 6. To prevent water leakage, install adequate roof flashing where the pipe enters the roof.
- 7. Do not locate vent over public walkways, driveways, or parking lots. Condensate could drip and freeze, resulting in a slip hazard or damage to vehicles and machinery.
- 8. Due to potential moisture build-up, sidewall venting may not be the preferred venting option. To save time and cost, carefully consider venting installation and location.
- 9. Horizontal lengths of exhaust vent must slope back towards the water heater not less than ¼" (6.3 mm) per foot to allow condensate to drain from the vent pipe.
- 10. The exhaust vent must terminate where vapors cannot make accidental contact with people or pets, or damage shrubs or plants.
- 11. In vacant chimney applications, install and seal a rain cap over existing chimney openings.
- 12. All piping must be fully supported. Use pipe hangers at a minimum of four (4) foot (1.2 m) intervals to prevent sagging of the pipe where condensate may form.
- 13. Do not use the heater to support any piping.
- 14. A screened straight coupling is provided with the heater for use as an outside exhaust termination.
- 15. A screened inlet air tee is provided with the heater to be used as an outside intake termination.

Table 8 lists optional intake air/exhaust vent terminations available from GIANT:

DESCRIPTION	STOCK CODE
2" (5 cm) PVC CONCENTRIC VENT TERMINATION KIT	KGAVT0501CVT
3" (7.6 cm) PVC CONCENTRIC VENT TERMINATION KIT	KGAVT0601CVT
2" (5 cm) STAINLESS STEEL VENT TERMINATION KIT	V500
3" (7.6 cm) STAINLESS STEEL VENT TERMINATION KIT	V1000
4" (10 cm) STAINLESS STEEL VENT TERMINATION KIT	V2000
3" (7.6 cm) POLYPRO VENT KIT	8400P-001

Table 8

H. VENTING DRAWINGS

1. DIRECT VENT INSTALLATION OF EXHAUST VENT AND INTAKE PIPE

If installing a direct vent option, combustion air must be drawn from the outdoors directly into the water heater intake, and exhaust must terminate outside. There are three (3) basic direct vent options detailed in this manual:

- 1. Side Wall Venting
- 2. Roof Venting
- 3. Unbalanced Venting

Be sure to locate the heater such that the exhaust vent and intake piping can be routed through the building and properly terminated. Different vent terminals can be used to simplify and eliminate multiple penetrations in the building structure (refer to the Venting Section). The exhaust vent and intake piping lengths, routing and termination methods must all comply with the methods and limits given in the Venting section, Part 5 of this manual.

When installing a combustion air intake from outdoors, care must be taken to utilize uncontaminated combustion air. **NOTE: To prevent combustion air contamination, see Table 1**: Contaminant Table.

A WARNING

Take extra precaution to adequately support the weight of vent pipes terminating through the roof. Failure to properly support roof terminated vent piping could result in property damage, serious personal injury, or death due to flue gas leakage.




Figure 11: Sidewall Venting - NOTE: This drawing is meant to demonstrate system venting only. The installer is responsible for all equipment and detailing required by local codes.




Figure 12: Concentric Venting - NOTE: This drawing is meant to demonstrate system venting only. The installer is responsible for all equipment and detailing required by local codes.




Figure 13: LP-179-F - NOTE: This drawing is meant to demonstrate system venting only. The installer is responsible for all equipment and detailing required by local codes.




Figure 14: Horizontal Venting - NOTE: Drawing is meant to demonstrate system venting ONLY.

- A. For every 1" (2.5 cm) of overhang, the exhaust vent must be located 1" (2.5 cm) vertical below overhang (overhang means top of building structure and not two adjacent walls [corner of building]).
- B. Typical installations require 12" (30 cm) minimum separation between bottom of exhaust outlet and top of air intake.
- C. Maintain 12" (30 cm) minimum clearance above highest anticipated snow level or grade (whichever is greater).
- D. Minimum 12" (30 cm) between vents when installing multiple vents.
- E. 12" (30 cm) minimum beyond air intake.

\Lambda WARNING

All vent pipes must be glued, properly supported, and the exhaust must be pitched a minimum of ¼" (6.3 mm) per foot back to the heater to allow drainage of condensate. When placing support brackets on vent piping, the first bracket must be within one (1) foot (30 cm) of the water heater and the balance at four (4) foot (1.2 m) intervals on the vent pipe. Heater venting must be readily accessible for visual inspection for the first three (3) feet (91 cm) from the heater.

2. VENTING THROUGH AN EXISTING SYSTEM

This heater may be vented through an existing unused vent system. The inner diameter of the existing vent system is utilized for the combustion air source. Two methods have been approved for such venting: Concentric Venting Through an Existing System and Venting as a Chase.

\Lambda DANGER

Do not install the heater into a common existing vent with any other appliance. This will cause flue gas spillage or heater malfunction, resulting in substantial property damage, severe personal injury, or death.

CAUTION

Contractors must check state and local codes before installing through an existing vent opening. State and local codes always take precedence over manufacturer's instructions. Failure to check state and local codes before installing through an existing opening could result in property damage and add significantly to installation costs.

CONCENTRIC VENTING THROUGH AN EXISTING SYSTEM

NOTE: The following instructions refer only to venting through an existing vent system, and not to venting with GIANT's concentric vent kits. Refer to Concentric Vent Kit installation manual (LP-166) for further concentric venting information and instructions.

Concentric venting through an existing system must run vertically through the roof. See Table 5 for proper minimum vent sizing. Use only the approved venting materials specified in Table 4 for piping the system. All instructions listed in Part 5 - Venting apply. See Figures 15-1 & 15-2 for venting demonstrations.

DANGER

The upper and lower vent terminations as well as all joints in the venting system must be properly sealed to ensure that all combustion air is drawn properly and exhaust does not leak from the system. Failure to properly seal the venting system will result in property damage, severe personal injury, or death.

NOTES:


A. For every 1" (2.5 cm) of overhang, the exhaust vent must be located 1" (2.5 cm) vertical below overhang (overhang means top of building structure and not two adjacent walls [corner of building]).

B. Typical installations require 12" (30 cm) minimum separation between bottom of exhaust outlet and top of air intake.

C. Maintain 12" (30 cm) minimum clearance above highest anticipated snow level or grade (whichever is greater).

D. Minimum 12" (30 cm) between vents when installing multiple vents.

E. 12" (30 cm) minimum beyond air intake. F. Maintain 12" (30 cm) minimum clearance above highest anticipated snow level or grade (whichever is greater).



Figures 15-1 & 15-2: Concentric Venting - NOTE: Drawing is meant to demonstrate system venting ONLY.

CAUTION

If an existing venting system is converted for use with this heater, the installer must ensure that the existing venting system is clean and free from particulate contamination that could damage the heater. Failure to do so could result in property damage and heater failure. Such failure IS NOT covered under warranty.

VENT / AIR INLET SIZE	MINIMUM EXISTING VENT / CHASE SIZE
2" (5 cm)	4" (10 cm)
3" (7.6 cm)	5" (13 cm)
4" (10 cm)	7" (18 cm)

Table 9 – Minimum Vent / Chase Sizing

VENTING AS A CHASE

When venting as a chase, follow all instructions included in Part 5 – Venting of this manual, as well as the previous Concentric Venting section. See Figure 16 for chase venting demonstration.

NOTES:

A. For every 1" (2.5 cm) of overhang, the exhaust vent must be located 1" (2.5 cm) vertical below overhang (overhang means top of building structure and not two adjacent walls [corner of building]).

B. Typical installations require 12" (30 cm) minimum separation between bottom of exhaust outlet and top of air intake.

C. Maintain 12" (30 cm) minimum clearance above highest anticipated snow level or grade (whichever is greater).

D. Minimum 12° (30 cm) between vents when installing multiple vents.

E. 12" (30 cm) minimum beyond air intake.

F. Maintain 12" (30 cm) minimum clearance above highest anticipated snow level or grade (whichever is greater).

3. INDOOR COMBUSTION AIR INSTALLATION IN CONFINED OR UNCONFINED SPACE

This heater requires fresh, uncontaminated air for safe operation and must be installed in a mechanical room where there is adequate combustion and ventilating air. **NOTE: To prevent combustion air contamination, see Table 1**: Contaminant **Table.**

Combustion air from the indoor space can be used if the space has adequate area or when air is provided through a duct or louver to supply sufficient combustion air based on the water heater input. **Never obstruct the supply of combustion air to the water heater.** If the water heater is installed in areas where indoor air is contaminated (see Figure 17) it is imperative that the water heater be installed as direct vent so that all combustion air is taken directly from the outdoors into the water heater intake connection.

Unconfined space is space with volume greater than 50 cubic feet per 1,000 Btu/hour (4.8 cubic meters per kW) of the total input rating of all fuel-burning appliances installed in that space. Rooms connected directly to this space, through openings not furnished with doors, are considered part of the space.

Confined space is space with volume less than 50 cubic feet per 1,000 Btu/hour (4.8 cubic meters per kW) of the total input rating of all fuel-burning appliances installed in that space. Rooms connected directly to this space, through openings not furnished with doors, are considered part of the space.

When drawing combustion air from inside a conventionally constructed building to a confined space, such space should be provided with two (2) permanent openings: one located 6" (15 cm) below the space ceiling, the other 6" (15 cm) above the space floor. Each opening should have a free area of one square inch per 1,000 Btu/hr ($22 \text{ cm}^2/\text{kW}$) of the total input of all appliances in the space, but not less than 100 square inches (645 cm²).

If the confined space is within a building of tight construction, air for combustion must be obtained from the outdoors as outlined in the Venting section of this manual. See **Figure 18**.




Figure 16: Venting as a Chase





Figure 17: LP-325-X





I. CONDENSATE REMOVAL SYSTEM

NOTE: Check with your local gas company to determine if combustion condensate disposal is permitted in your area.

This condensing high efficiency water heater has a condensate removal system. Condensate is water vapor derived from combustion products, similar to an automobile when it is initially started. It is very important that the condensate line is sloped down away from the heater and to a suitable drain.

If the heater condensate outlet is lower than the drain, you must use a condensate removal pump (kit p/n 554200 available from GIANT). If required by local authorities, a condensate filter of lime crystals, marble, or phosphate chips will neutralize slightly acidic condensate. This can be installed in the field and purchased from GIANT (p/n 7450P-212).

CAUTION

The condensate line must remain unobstructed. If allowed to freeze in the line or obstructed in any other manner, condensate can exit from the water heater tee, resulting in potential water damage to property. When installing a condensate pump, select one approved for use with condensing heaters and furnaces. The condensate pump should have an overflow switch to prevent property damage from spillage. Condensate from the heater will be slightly acidic (pH from 3.2 to 4.5). Install a neutralizing filter if required by local codes.




Figure 19: LP-179-K

NOTES:

1. Condensate line must be pitched at least ¼" (6.3 mm) per foot to properly drain. If this cannot be done, or a very long length of condensate hose is used, increase the condensate line to a minimum of 1" (2.5 cm) ID and place a tee in the line after the condensate neutralizer to properly reduce vacuum lock in the drain line.

2. Plastic pipe should be the only material used for condensate line. Steel, brass, copper, and other metals will be subject to corrosion or deterioration.

3. NEVER install condensate lines outside. It is very important that the condensate line is not exposed to freezing temperatures or any type of blockage. Damages due to frozen or blocked condensate lines ARE NOT covered by warranty.

4. Support of the condensate line may be necessary to avoid blockage of the condensate flow.

PART 6 – WIRING

To avoid electrical shock, turn off all power to the heater prior to opening an electrical box within the unit. Ensure the power remains off while any wiring connections are being made. Failure to follow these instructions could result in component or product failure, serious injury, or death. Such product failure IS NOT covered by warranty.

A. LINE VOLTAGE INPUT

The heater must be wired to a 120 volt circuit by a qualified electrician. It is recommended that the heater be wired on its own circuit to minimize the possibility of circuit failure due to outside causes. The heater requires a maximum of 8 amps at 120 volts in use.

B. LINE VOLTAGE CONDENSATE OUTPUT

The heater has the capability of supplying power to a condensate pump. The connection is 120 VAC +/- 10% at a max of 2 amps. Power is supplied to the pump only when the heater is connected to power, and the power switch is in the on position.

C. LOW VOLTAGE OUTDOOR SENSOR INPUT

The heater has the capability of an outdoor reset. Connecting an outdoor sensor allows the heater to operate at optimum efficiency. GIANT offers an outdoor sensor, p/n 7250P-319.

The outdoor sensor must be a 12K NTC sensor. Use a minimum 22 AWG wire for runs of 100 feet (30.5 m) or less and minimum 18 AWG wire for runs up to 150 feet (45.7 m). Instructions are included with the outdoor sensor to correctly mount the sensor on the exterior surface of the building. It is preferable to mount the sensor on the north side in an area that will not be affected by direct sunlight but will be exposed to varying weather conditions. Connect the outdoor sensor to terminals marked "Outdoor".

A WARNING

It is of extreme importance that this unit be properly grounded. It is very important that the building system ground is inspected by a qualified electrician prior to making this connection. Electrical power must only be turned on when the heater is completely filled with cold water.




Figure 20: Low Voltage Wiring

Label all wires prior to disconnecting them when servicing the heater. Wiring errors can cause improper and dangerous operation. Failure to follow these instructions may result in property damage or personal injury.

D. INTERNAL WIRING DIAGRAM




Figure 21: Wiring Diagram




Figure 22: LP-179-L

PART 7 – GAS CONNECTIONS

A WARNING

Failure to follow all precautions could result in fire, explosion, severe injury or death!

The gas supply shall have a maximum inlet pressure of less than 14" water column (35.6 cm), $\frac{1}{2}$ pound pressure (3.5 kPa), and a minimum of 3.5" water column (8.9 cm). The entire piping system, gas meter and regulator must be sized properly to prevent pressure drop greater than 0.5" WC (1.3 cm) as stated in the National Fuel Gas Code. This information is listed on the rating plate.

It is very important that you are connected to the type of gas as noted on the rating plate: "LP" for liquefied petroleum, propane gas, or "Nat" for natural or city gas. All gas connections must be approved by the local gas supplier or utility, in addition to the governing authority, prior to turning the gas supply on.

Do not remove the adaptor in Figure! It is mandatory that this fitting is used for connection to a field fabricated drip leg per the National Fuel Gas Code. You must ensure that the entire gas line to the connection at the water heater is no smaller than $\frac{3}{4}$ " (1.9 cm).

Once all inspections have been performed, the piping must be leak tested. If the leak test requirement is a higher test pressure than the maximum gas inlet pressure, you must isolate the heater from the gas line to continue leak testing. To do this, you must turn off the factory and field-installed gas cocks. This will minimize the possibility of damaging

the gas valve. Failure to do so may damage the gas valve. In the event the gas valve is exposed to a pressure greater than $\frac{1}{2}$ PSI, 14" water column (35.6 cm), the gas valve must be replaced. Never use an open flame (match, lighter, etc.) to check gas connections.

A. GAS PIPING

Run the gas supply line in accordance with all applicable codes. Locate and install manual shutoff valves in accordance with local and state requirements.

B. GAS TABLE

Refer to the table below to size the supply piping to minimize pressure drop between meter or regulator and unit.

Maximum capacity of pipe in cubic feet of gas per hour for gas pressures of .5 psi or less and a pressure drop of .3 inch water column (7.6 mm).




Figure 23: Phoenix Gas Connection - LP-179-Q



Nominal Iron	Internal	Length of Pipe (Feet)														
Pipe Size (In.)	Dia. (In.)	10	20	30	40	50	60	70	80	90	100	125	150	175	200	
¾ (1.9 cm)	.824 (2.1 cm)	278	190	152	130	115	105	96	90	84	79	72	64	59	55	BTU's Per
1 (2.5 cm)	1.049 (2.7 cm)	520	350	285	245	215	195	180	170	160	150	130	120	110	100	Hour x 1,000
1 ¼ (3.2 cm)	1.380 (3.5 cm)	1,050	730	590	500	440	400	370	350	320	305	275	250	225	210	,
1 ½ (3.8 cm)	1.610 (4.1 cm)	1,600	1,100	890	760	670	610	560	530	490	460	410	380	350	320	

Table 10: Source- ANSI Z223.1

It is recommended that a soapy solution be used to detect leaks. Bubbles will appear on the pipe to indicate a leak is present. The gas piping must be sized for proper flow and length of pipe to avoid excessive pressure drop. Both the gas meter and the gas regulator must be properly sized for the total gas load. If you experience a pressure drop greater than 1" WC (2.5 cm), the meter, regulator or gas line is undersized or in need of service. You can attach a manometer to the incoming gas drip leg by removing the cap. The gas pressure must remain between 3.5" WC (8.9 cm) and 14" WC (35.6 cm) during stand-by (static) mode and while in operating (dynamic) mode at full output.

If an in-line regulator is used, it must be a minimum of ten (10) feet (3 m) from the heater. It is very important that the gas line is properly purged by the gas supplier or utility. Failure to properly purge the lines or improper line sizing will result in ignition failure. This problem is especially noticeable in NEW LP installations and also in empty tank situations. This can also occur when a utility company shuts off service to an area to provide maintenance to their lines. The gas valve must not be replaced with a conventional gas valve under any circumstances. As an additional safety feature, the gas valve in this water heater has a flanged connection to the swirl plate and blower.

C. GAS VALVE




Figure 24: Gas Valve LP-179-P

\Lambda DANGER

Do not do a gas conversion on this water heater without an officially approved conversion kit and instructions supplied by GIANT. Failure to use a conversion kit when converting the heater to fire on Natural or LP gas will result in extremely dangerous burner operation, leading to fire, explosion, severe injury or death.

A WARNING

Strain on the gas valve and fittings may result in vibration, premature component failure and gas leakage, and result in fire, explosion, property damage, severe personal injury, or death.

A WARNING

Adjustments to the throttle screw or offset may only be made by a qualified gas technician using a calibrated combustion analyzer capable of measuring CO₂ and CO. Failure to follow this instruction could result in fire, explosion, property damage, severe personal injury, or death.

PART 8 – START-UP PROCEDURE

A WARNING

FOR YOUR OWN SAFETY READ BEFORE OPERATING

1. This water heater does not have pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.

2. BEFORE OPERATING: smell all around the water heater area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any water heater.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas suppliers' instructions.
- If you cannot reach your gas supplier, call the fire department.
- Turn off gas shutoff valve (located outside of the water heater) so that the handle is crosswise to the gas pipe. If the handle will
 not turn by hand, don't try to force or repair it, call a qualified service technician. Force or attempted repair may result in a fire
 or explosion.

3. Do not use this water heater if any part has been under water. Immediately call a qualified service technician to inspect the water heater and to replace any part of the control system and any gas control that has been damaged.

4. The water heater shall be installed so the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during water heater operation and service (circulator replacement, condensate trap, control replacement, etc.)

Failure to follow these instructions could result in property damage, serious personal injury, or death.

A. OPERATING INSTRUCTIONS

If you smell gas, **STOP**. Follow listed safety instructions above. If you do not smell gas, follow the next steps.

1. Turn on all electric power to water heater. Make sure tank is full with cold water and purge all piping. To assure adequate purging, open all hot water faucets.

WARNING

Ensure the water heater is full of water before firing the burner. Failure to do so will damage the heater. Such damage IS NOT covered by warranty, and could result in property damage, serious personal injury, or death.

2. Adjust the temperature set point of the heater to the desired level. The factory default setting is 119°F (48°C). If changes are necessary, follow "Overall Water Heater and Control Operation" in this section.

3. If the water heater fails to start, refer to the Troubleshooting section in the back of this manual.

B. OVERALL WATER HEATER AND CONTROL OPERATION

In order to adjust the temperature of stored water, press and hold 33 for two (2) seconds. The first item is D: Water Temperature Set Point – factory set at 119°F (48°C). Adjust down by pressing 31 to a temperature as low as 95°F (35°C). Adjust up as high as 160°F (71°C) by pressing the 32. Press 33 again to display D, the differential which is factory set at 7°F (-14°C) and adjustable down to 1°F (-17°C) by pressing 31 and up to 18°F (-8°C) by pressing 32. Note: Due to the highly advanced control on this water heater, which compensates for varying inlet water temperature, the actual differential temperature may vary slightly from your setting. Press again to display the factory default temperature measurement in Fahrenheit. Change the default to Celsius by pressing 31. When finished, press 33 one final time to place unit back into operation. The control automatically re-starts if no key is pressed for two (2) minutes.

C. STATUS MENU

Installers are also able to check the current status of the heater parameters by pressing [S4] for three (3) seconds. Once activated, the display will show d1 alternating value of the actual upper supply tank temperature. Actual values are displayed for each function. To view the next value, simply press [S/4] to go to the next displayed value. Listed below are the values which can be displayed. These values cannot be changed. To exit this menu, press [S3] to resume normal operation.

Function	Value				
d1	Actual temperature from upper tank sensor				
d2	Actual temperature from lower sensor				
d3 — 0	(Not used)				
d4 — <mark> 308</mark>	(Not used)				
d5	Outdoor sensor				
d6	Actual fan speed multiplied by 10 (Example: If fan speed displayed is 410 RPM x 10 = 4100 actual fan speed)				
d7	Actual ionization current read from flame rectification probe				
d8 — 0	(Not used)				
d9 — 1	(Not used)				
d10	Actual status of bus communication col = connected, nc = not connected				
d11 — <mark>32</mark>	(Not used)				
d12	Power on hours in thousands (display will not read until 100 hrs.)				
d13	Total water heating hours in thousands (display will not read until 100 hrs.)				
d14 — 🚺	(Not used)				
d15	Passed ignition attempts in thousands				

D. OUTDOOR RESET

This unit is supplied with outdoor reset wire connection terminals. When an outdoor sensor (p/n 7250P-319) is connected, operation of the unit immediately changes. Refer to the following steps to properly set up the unit with an outdoor sensor.

DANGER

An ASSE 1017 thermostatic mixing valve MUST be installed when using outdoor reset. Failure to do so could result in substantial property damage, serious injury, or death.

1. Connect the outdoor sensor to the terminals marked "Outdoor".

2. Press and hold [S3]. You will see a flashing DU and a temperature value. Set DU to the maximum desired tank temperature (default 119°F (48°C)). After you set the temperature; press S3 until you exit the menu.

3. Setting the outdoor reset curve (change only the functions in the descriptions below):

a. Press and hold [S3] and [S4] together for five (5) seconds b. Use [S1] and [S2] to adjust flashing [000] to code [975]. Press [S3] until you enter the menu. c. Use [S3] to scroll to Function 8 to adjust minimum outdoor temperature. Use [S1] and [S2] to adjust temperature to desired setting (Range: -49°F (-45°C) – 32°F (0°C) / Default 5°F (-15°C)).

d. Use (S3) to scroll to Function 9 to adjust maximum supply temperature. Use (S1) and (S2) to adjust temperature to desired setting (Range: 77°F (25°C) – 160°F (71°C) / Default 119°F (48°C)). It is recommended that the du setting matches Function 9. e. Use [S3] to scroll to Function 10 to adjust maximum outdoor temperature. Use [S1] and [S2] to adjust temperature to desired setting (Range: $32^{\circ}F(0^{\circ}C) - 95^{\circ}F(35^{\circ}C)$ / Default $68^{\circ}F(20^{\circ}C)$).

f. Use [S3] to scroll to Function 11 to adjust minimum supply temperature. From the water heater, use [S1] and [S2] to adjust temperature to desired setting. It is recommended that this temperature is set to the minimum desired DHW temperature (Range: 32°F (0°C) - 160°F (71°C) / Default 120°F (49°C)).

g. Use [S3] to scroll to Function 12 to adjust desired DHW temperature (minimum tank temperature). Use [S1] and [S2] to adjust temperature to desired setting. It is recommended that this is the same temperature set in Function 11 (Range: 32°F (0°C) – 160°F (71°C) / Default 120°F (49°C)).

h. Press and hold [S4] to exit the menu




Figure 25 - NOTE: The maximum tank temperature is 160°F (71°C), independent of all settings described above.

E. TEST MODE

This function is intended to simplify the gas valve adjustment if needed. Listed below are the recommended limits on each heater and the combustion settings. Automatic modulation does not take place when the controller is in Test mode, only temperature limitation based on the heater set point. The user will be allowed to increase or decrease the fan speed by pressing in either the **S1** or **S2** keys.

To activate the Test Mode simply press the [S2] and [S3] key together for one (1) second. Once activated, you will see in the display [Ser] and the actual fan speed. The measurement of the combustion levels should always be taken at the highest and lowest fan speed. When in Test Mode, the heater's limit will shut down the burner if temperature limit is exceeded. It is recommended to draw water out of the tank to lower temperature so tests can be performed.

After ten (10) minutes, Test Mode stops automatically. To exit Test Mode manually, press [S1] and [S2] key together for one (1) second.

COMBUSTION SETTINGS HIGH FIRING RATES and LOW FIRING RATES ON ALL MODELS							
	NAT	URAL GAS	PRO	ROPANE LP			
	Low	High	Low	High			
Carbon Monoxide (CO%)	0 – 10 ppm	0 – 20 ppm	0 – 10 ppm	0 – 20 ppm			
Carbon Dioxide (CO ₂ %)	9 – 10.5%	9 – 10.5%	9.5 – 11%	9.5 – 11%			

Table 11

	FAN SPEEDS						
BTU	IGNITION	MIN	MAX				
100,000	3,000	2,000	5,700				
130,000	3,000	2,000	7,300				
160,000	3,000	2,000	7,450				
199,000	3,000	2,000	9,100				

Table 12

F. MAINTENANCE

The control system requires no periodic maintenance under normal conditions. However, in unusually dirty or dusty conditions, periodic vacuuming of the cover to maintain visibility of the display and indicators is recommended. In dirty environments, such as construction sites, care must be taken to keep the water heater burner cover in place and drywall or saw dust away from water heater.

In unusually dirty or dusty conditions, care must be taken to keep water heater burner door in place. Failure to do so VOIDS WARRANTY!

Allowing the heater to operate with a dirty combustion chamber will hurt operation. Failure to clean the heat exchanger as needed by the installation location could result in heater failure, property damage, personal injury, or death. Such product failures ARE NOT covered under warranty.

PART 9 – SHUTDOWN

A. SHUTDOWN PROCEDURE

If the burner is not operating, disconnect the electrical supply.

If the burner is operating, lower the set point value to 70° F (21° C) and wait for the burner to shut off. Continue to wait for the combustion blower to stop, so all latent combustion gases are purged from the system. This should take a maximum of 40 to 90 seconds.

B. VACATION PROCEDURE

If there is danger of freezing, change the set point to 70°F (21°C). DO NOT turn off electrical power. If there is no danger of freezing, follow "Shutdown Procedure".

C. FAILURE TO OPERATE

Should the burner fail to light, the control will perform two more ignition trials prior to entering a lockout state. Note that each subsequent ignition trial will not occur immediately. After a failed ignition trial, the blower must run for approximately ten (10) seconds to purge the system. Therefore, a time period of approximately 40 to 90 seconds will expire between each ignition trial.

If the burner lights during any one of these three (3) ignition trials, normal operation will resume. If the burner lights, but goes off in about four (4) seconds, check the polarity of the wiring. See electrical connection section.

If the burner does not light after the third ignition trial, the control will enter a lockout state. This lockout state indicates that a problem exists with the water heater, the controls, or the gas supply. Under such circumstances, a qualified service technician should be contacted immediately to properly service the water heater and correct the problem. If a technician is not available, depressing the **[S4]** button once will remove the lockout state so additional trials for ignition can be performed. The unit will try to re-light once every six (6) minutes.

PART 10 – TROUBLESHOOTING

A. ERROR CODE

An error code may occur during installation of the heater. This condition may lead to a lock out condition of the controller, which will need to be manually reset by pressing the share button. These following will help the installer correct the problem before going into a lock out condition, which will require a manual reset.

B. HEATER ERROR

1. When an error condition occurs the controller will display an error code on the display module.

2. These error codes and several suggested corrective actions are included in Table 14.

3. In the case of [E00], [E13], and [E14] this error, if uncorrected, will go into a fault condition as described in Paragraph C.

C. LOCKOUT

1. When a fault condition occurs the controller will illuminate the red "fault" indication light and display a fault code in the format (Example: **F00**) on the display module.

RESISTANCE TABLE FOR SUPPLY TEMPERATURE SENSOR					
RESISTANCE (ohms)					
32,550					
25,340					
19,870					
15,700					
12,490					
10,000					
8,059					
6,535					
5,330					
4,372					
3,605					
2,989					
2,490					
2,084					
1,753					
1,481					
1,256					
1,070					
915					
786					
667					

Table 13

2. Note the fault code and refer to Table 15 for an explanation of the fault code along with several suggestions for corrective actions.

3. Press the reset key to clear the fault and resume operation. Be sure to observe the operation of the unit to prevent a recurrence of the fault.

A WARNING

When servicing or replacing any components of this water heater be certain that:

- The gas is off.
- All electrical power is disconnected.

A DANGER

When servicing or replacing components that are in direct contact with heater water, be certain that:

- There is no pressure in the heater. Pull the release on the relief valve to relieve pressure in the heater.
 - Heater water is not hot.
 - The electrical power is off.

A WARNING

DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN SUBMERGED IN WATER. Immediately call a qualified service technician. The appliance MUST BE replaced if it has been submerged. Attempting to operate an appliance that has been submerged could create numerous harmful conditions, such as a potential gas leakage causing a fire and/or explosion, or the release of mold, bacteria, or other harmful particulates into the air. Operating a previously submerged appliance could result in property damage, severe personal injury, or death.

NOTE: Appliance damage due to flood or submersion is considered an Act of God, and IS NOT covered under product warranty.

The water heater has wire function labels on all internal wiring. Observe the position of each wire before removing it. Wiring errors may cause improper and dangerous operation. Verify proper operation after servicing.

	926 CONTROL BOARD ERROR CODES						
CODE	DESCRIPTION	DURATION	CORRECTIVE ACTION				
E13	Heater combustion air fan speed less than 70% of expected.	60 Sec.	 Check the combustion air fan wiring. Replace the combustion air fan. Replace the control board. 				
E14	Heater combustion air fan speed is more than 130% of expected.	60 Sec.	 Check the combustion air fan wiring. Replace the combustion air fan. Replace the control board. 				
LEO	Water Level in Tank is Low	Until Corrected	 Be sure all air is bled from system. Inspect low level switch and wiring for damage and repair if necessary. 				
FLU	Blocked Vent, Pressure Switch open, Condensate cup Full, Condensate Cup not present	Until Corrected	 Check the flue vent to be sure it is not blocked or damaged. Check the blocked vent pressure switch operation by applying a jumper. (If the switch is not functioning properly, replace it. 				
LOU	24 Volt Low	Until Corrected	 Check line voltage. Must be between 100 – 128 volts. If available, connect a PC and, using GIANT service software, check the 24v supply display in the lower left corner of the screen. The number displayed must be greater than 128 and should be greater than 250. Use this as a troubleshooting guide as you follow the steps below. Remove 10 pin Molex connector from customer connection board. If LOU clears, the problem is with external sensor wiring. Examine external sensor wiring for shorts to ground, repairing as necessary. If LOU code is still present and the heater is so equipped, disconnect high gas pressure switch, then low gas pressure switch, then UL 353 low water cutoff in this order, one at a time, to see if LOU code clears. Replace faulty part. Check low voltage wire harness in heater for shorts to ground. If LOU only occurs when burner tries to light, check gas valve for excessive current draw. If LOU is present with the low voltage harness disconnected from the 926 control board, replace the 926 control board. 				

Table 14: Control Board Error Codes

		926 CONTROL BOARD FAULT
CODE	DESCRIPTION	REMEDY
F00	High temperature switch limit exceeded 194°F (90°C).	 Try reset. If F00 repeats, create a demand for hot water. (DANGER: Use caution to prevent burn injury.) If water is above 194°F (90°C), test upper and lower temperature sensor with an ohmmeter. (Refer to resistance chart, this section.) Replace bad sensor. If water is below 194°F (90°C), test high temperature switch and wiring with ohmmeter. Switch should be closed at this point. If not, replace switch. If unit did reset successfully, let the heater run and go into the status menu to check the upper and lower temperature sensor. If either reading displayed does not make sense, check appropriate sensor with ohmmeter. (Refer to resistance chart, this section.) Replace bad sensor. Do an OHMs reading on both sensors to check continuity.
F01	Vent temperature limit exceeded.	 Inspect all flue piping. If the flue is damaged or shows signs of overheating, repair or replace the flue parts as necessary before proceeding. If the flue piping system is intact, not damaged and there is no sign of the flue overheating (such as discoloration or melting), push the red reset button on the flue switch Be sure the heater is connected to a water supply and full of water. Push the RESET button on the heater control panel. The water heater should light. If the water heater lights, proceed to step 5. If the water heater does not light and the display again begins to flash F01, inspect the wiring to the flue switch, repairing or replacing as necessary. If the wiring is intact, replace the flue switch, using care to mount the new flue switch in the same position and mounting holes as the old one. If the display flashes a code other than F01, follow the troubleshooting guide for that code. Observe operation for five (5) minutes. Place the probe of an exhaust analyzer into the flue system within six (6) feet (1.8 m) of the heater. The exhaust temperature should not rise above 190°F (88°C) after several minutes of operation. If the flue temperature is below 190°F (88°C) and the heater again goes into lockout displaying F01, replace the flue switch, using care to mount the new flue switch in the same position and mounting holes as the old one. If the display flashes a code other than F01, follow the troubleshooting guide for that code. If the flue temperature is below 190°F (88°C) and the heater again goes into lockout displaying F01, replace the flue switch, using care to mount the new flue switch in the same position and mounting holes as the old one. If the display flashes a code other than F01, follow the troubleshooting guide for that code. If the flue temperature increases to over 190°F (88°C), consult GIANT for further assistance.
F02	Interrupted or shorted upper temperature sensor.	 Check the electrical connection to the appropriate temperature sensor. If connection is okay, replace bad sensor.
F03	Interrupted or shorted lower temperature sensor.	
F05	Upper temperature sensor exceeds 194°F (90°C).	 If water in tank is not greater than 194°F (90°C), check wiring. Repair if faulty. If wiring is okay, check appropriate sensor with ohmmeter and compare to reading in resistance chart above.
F06	Lower temperature sensor exceeds 194°F (90°C).	If reading does not agree with water temperature, replace bad sensor.
F09	No flame detected – Heater will make three (3) attempts at ignition before the control goes into this lockout condition. Will reset in one (1) hour.	 Watch the igniter through the observation window provided. If there is no spark, check the spark electrode for the proper ¼" (6.3 mm) gap. Remove any corrosion from the spark electrode and flame rectifier probe. If there is a spark but no flame, check the gas supply to the heater. If there is a flame, check the flame sensor. Check any flue blockage or condensate blocks.
F10	Loss of flame signal – The heater will relight four (4) times before the control goes into this lockout condition. Will reset in one (1) hour.	 Oncertain the discrete the unit while in operation. Assure that the flame is stable when lit. Check to see if the green light on the display module is out while the heater is running. If the green light doesn't come on or goes off during operation check the flame signal on the status menu. If the signal reads less than 1 microampere, clean the flame rectifier probe. If the flame rectifier probe continues to read low, replace it.
F11	False flame signal – The heater will lock out if it senses a flame signal when there should be none present.	 Turn the gas off to the unit at the service valve. If the flame signal is still present replace the igniter. If the flame signal is not present after turning off the gas supply, check the gas valve electrical connection. If there is no power to the gas valve, remove the valve and check for obstruction in the valve seat or replace the gas valve. Turn the gas on at the service valve after corrective action is taken.
F13	Combustion fan speed incorrect – The heater will lock out if it senses that the fan speed is less than 70% of expected rate for more than 60 seconds.	 Check the combustion air fan wiring. Replace the combustion air fan. Replace the control board.

Table 15 - NOTE: If you replace a part to remedy a fault, it is recommended that you cycle the unit at least three or four times to assure the fault has been resolved.





Figure 26: LP-179-J



ltem #	Description Replacer Part #		Item #	Description	Replacement Part #
1	GASKET - MOUNTING PLATE	7100P-139	15	ADAPTER PLATE	7250P-644
2	MOUNTING PLATE	7100P-007	16	FLAT HEAD SCREW - ADAPTER PLATE	7100P-045
3	GASKET - PROBES	7100P-155	17	AIR INTAKE ADAPTER - BLOWER SIDE	7500P-185
4	FLAME RECTIFICATION PROBE (w/GASKET)	7100P-082	18	SWIRL PLATE - BLACK (100/130 BTU)	7100P-042
5	IGNITOR ELECTRODE (w/GASKET)	7100P-124		SWIRL PLATE - WHITE (160/199 BTU)	7500P-092
6	10-32 X 3/8 SCREWS/#10 LOCK WASHERS	N/A	19	AIR INTAKE ADAPTER - VALVE SIDE	7500P-184
7	NUTS - 5/16-18	N/A	20	GAS VALVE (100/130 BTU)	7000P-862
8	GASKET - BURNER MOUNTING FLANGE	7100P-152		GAS VALVE (160/199 BTU)	7000P-863
9	BURNER - 100-130K BTU	7100P-316	21	SCREWS - GAS VALVE	7100P-046
	BURNER - 160-199K BTU	7100P-317	22	1/2" FLARE X 1/2" NPT FLEX HOSE	7100P-140
10	GASKET - BURNER OUTLET	7000P-361	23	TUBE - AIR INLET	7500P-189
11	GASKET - SIGHT GLASS	7100P-105	24	GAS VALVE ADAPTER (w/O-RING)	7250P-454
12	SIGHT GLASS	G2000	25	SCREWS - M4 X 20MM GAS VALVE ADAPTER	7250P-717
13	COMBUSTION BLOWER (w/GASKET, SIGHT GLASS)	7100P-015	26	GAS SHUT-OFF VALVE	7250P-140
	COMBUSTION BLOWER (w/GASKET, SIGHT GLASS)199K BTU ONLY	7100P-350	27	24VAC GAS VALVE COIL ONLY - GREY	7350P-624
14	1/4-20 BRASS NUTS/1/4 LOCK WASHERS	7100P-268			

Figure 27: LP-179-H

PART 11 - MAINTENANCE

CAUTION

In unusually dirty or dusty conditions, care must be taken to keep water heater cabinet door in place at all times. Failure to do so VOIDS WARRANTY!

A WARNING


Allowing the water heater to operate with a dirty combustion chamber will hurt operation. Failure to clean the heat exchanger as needed by the installation location could result in water heater failure, property damage, personal injury, or death. Such product failures ARE NOT covered under warranty.

The water heater requires minimal periodic maintenance under normal conditions. However, in unusually dirty or dusty conditions, periodic vacuuming of the cover to maintain visibility of the display and indicators is recommended.

Periodic maintenance should be performed once a year by a qualified service technician to assure that all the equipment is operating safely and efficiently. The owner should make necessary arrangements with a qualified heating contractor for periodic maintenance of the heater. Installer must also inform the owner that the lack of proper care and maintenance of the heater may result in a hazardous condition.

	INSPECTION ACTIVITIES	DATE LAST COMPLETED				
PIPING		1 st YEAR	2 nd YEAR	3 rd YEAR	4 th YEAR*	
Near heater piping	Check heater and system piping for any sign of leakage; make sure they are properly supported.					
Vent	Check condition of all vent pipes and joints. Ensure the vent piping terminations are free of obstructions and blockages.					
Gas	Check Gas piping, test for leaks and signs of aging. Make sure all pipes are properly supported.					
SYSTEM						
Visual	Do a full visual inspection of all system components.					
Functional	Test all functions of the system (Heat, Safeties)					
Temperatures	Verify safe settings on heater or Anti-Scald Valve					
Temperatures	Verify programmed temperature settings					
ELECTRICAL						
Connections	Check wire connections. Make sure they are tight.					
Smoke and CO detector	Verify devices are installed and working properly. Change batteries if necessary.					
Circuit Breakers	Check to see that the circuit breaker is clearly labeled. Exercise circuit breaker.					
CHAMBER/BURNER						
Combustion Chamber	Check burner tube and combustion chamber coils. Clean according to maintenance section of manual. Vacuum combustion chamber. Replace any gaskets that show signs of damage.					
Spark Electrode	Clean. Set gap at $\frac{1}{4}$ (6.3 mm).					
Flame Probe	Clean. Check ionization in uA (d7 on status menu in Start-up Procedures). Record high fire and low fire.					
CONDENSATE						
Neutralizer	Check condensate neutralizer. Replace if necessary.					
Condensate hose	Disconnect condensate hose. Clean out dirt. Fill with water to level of outlet and re-install. (NOTE: Verify the flow of condensate, making sure that the hose is properly connected during final inspection.)					
GAS						
Pressure	Measure incoming gas pressure (3.5" (8.9 cm) to 10" (25 cm) W.C. for Natural Gas, 8" (20 cm) – 14" (36 cm) W.C for LP)					
Pressure Drop	Measure drop in pressure on light off (no more than 1" (2.5 cm) W.C.)					
Check gas pipe for leaks	Check piping for leaks. Verify that all are properly supported.					
COMBUSTION			·	·	·	
CO/CO ₂ Levels	Check CO and CO ₂ levels in Exhaust (See Start-up Procedures for ranges). Record at high and low fire.					
SAFETIES						
ECO (Energy Cut Off)	Check continuity on Flue and Water ECO. Replace if corroded.					
Upper/Lower Sensors	Check wiring. Verify through ohms reading.					
FINAL INSPECTION			·			
Check list	Verify that you have completed entire check list. WARNING: FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.					
Homeowner	Review what you have done with the homeowner.					

Table 16 - *Continue annual maintenance beyond the 4th year as required.



GIANT CUSTOMER INSTALLATION RECORD FORM

The following form should be completed by the installer for you to keep as a record of the installation in case of a warranty claim. After reading the important notes at the bottom of the page, please also sign this document.

Customer's Name:	
Installation Address:	
Date of Installation:	
Installer's Code/Name:	
Product Serial Number(s):	
Comments:	
Installer's Phone Number:	
Signed by Installer:	
Signed by Customer:	

IMPORTANT:

Customer: Please only sign after the installer has reviewed the installation, safety, proper operation and maintenance of the system. In the case that the system has any problems, please call the installer. If you are unable to make contact, please contact your GIANT Sales Representative.

Distributor/Dealer: Please insert contact details.



Enhancing everyday living

Giant Factories Inc.

Telephone: (514) 645-8893 Toll free: 1-800-363-9354 General fax: (514) 640-0969 Customer Service fax: (514) 645-8413

www.giantinc.com